

Maintenance

Audi A6 2011 ➤

Audi A7 Sportback 2011 ➤

Edition 06.2015



Audi

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Maintenance

Heading

1. General information
2. Preparations
3. Maintenance



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Technical information should always be available to the foremen and mechanics, because their careful and constant adherence to the instructions is essential to ensure vehicle road-worthiness and safety. In addition, the normal basic safety precautions for working on motor vehicles must, as a matter of course, be observed.

Contents

1	General information	1
1.1	--- Change history ---	1
1.2	Overview of engines	1
1.3	Engine number	6
1.4	Vehicle identification number	9
1.5	Vehicle data sticker	9
1.6	Warnings for high-voltage vehicles	10
2	Preparations	15
2.1	Vehicle: raising	15
2.2	Engine cover panel: removing and installing	17
2.3	Noise insulation: removing and installing	21
2.4	Window regulators: activating automatic open/close function	23
2.5	Vehicle diagnostic tester: connecting	23
3	Maintenance	26
3.1	Diesel particulate filter: reading out ash deposit volume	28
3.2	Event memory: reading out and erasing	29
3.3	Service interval display: resetting service	30
3.4	Transport mode: deactivating	30
3.5	Shipping mode: deactivating	31
3.6	Battery: reading out status and sending diagnostic log	31
3.7	Battery: checking that battery and battery cables are securely fitted	33
3.8	Battery: checking electrolyte level	36
3.9	Battery: connecting to a stationary battery charging unit for sustained charging	39
3.10	Brake fluid: changing	43
3.11	Brake fluid: checking fluid level	48
3.12	Brake system: checking condition of brake hoses, and checking that caps are fitted on bleeder screws	48
3.13	Brake pads: checking thickness	49
3.14	Tyres: checking condition and wear pattern, and checking and recording tread depth	50
3.15	Tyres: checking tyre pressures and adjusting if necessary	51
3.16	Tyre Pressure Loss Indicator: storing changed tyre pressures	52
3.17	Tyre repair kit: checking that set is complete, and checking and recording expiry date	53
3.18	Tool kit: checking that all components necessary in the event of a breakdown are present	53
3.19	Wheel bolts: tightening to specified torque	54
3.20	Suspension struts on front and rear axle: removing locking elements	54
3.21	Components of front and rear axles: checking play, secure attachment and protective boots	56
3.22	Engine, gearbox, final drive and steering: checking for leaks and damage	60
3.23	Underbody: checking trim, wheel housing liners, side members and pipes/wiring for damage, and checking that they are properly secured	61
3.24	Roof insert: checking operation	61
3.25	Roof insert - sliding/tilting sunroof: cleaning and lubricating	61
3.26	Roof insert - panorama sunroof: cleaning and lubricating	64
3.27	Rear spoiler hinges: lubricating	68
3.28	Bonnet arrester hook: lubricating	68
3.29	Windscreen/rear window washer system: checking spray pattern and adjusting if necessary	69
3.30	Wiper blades: checking for damage	71
3.31	Headlight washer system: checking operation	71
3.32	Headlights: checking for correct adjustment	72
3.33	Headlights and reversing lights, side lights, number plate lights, turn signals, hazard warning lights: checking operation	73
3.34	Luggage compartment lighting: checking operation	74
3.35	Glove box light, interior lighting and reading light: checking operation	75

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Audi AG. Audi AG does not guarantee or accept any liability with respect to the content of this document. Copyright by AUDI AG.

3.36	Horn: checking operation	76
3.37	Front passenger's airbag: checking key switch on / off and setting to "on"	76
3.38	Seat belts: checking that retaining rivets are fitted, and checking locking action of automatic belt retractor	77
3.39	Instrument cluster: checking warning lamps	77
3.40	Warning triangle: checking availability	78
3.41	First-aid kit: checking and recording expiry date	78
3.42	Vehicle keys: checking operation and recording number of keys given to customer	78
3.43	Engine oil: draining	79
3.44	Engine oil: extracting	81
3.45	Engine oil: renewing oil filter	82
3.46	Engine oil: filling up	89
3.47	Engine oil: checking oil level and correcting if necessary	90
3.48	Poly V-belts for ancillaries: checking	92
3.49	Spark plugs: renewing	93
3.50	Cooling system: checking anti-freeze and coolant level, and correcting if necessary	102
3.51	Air cleaner: renewing filter element and cleaning housing	105
3.52	Plenum chamber and water drains: checking for dirt	113
3.53	Dust and pollen filter: renewing	115
3.54	Fuel filter: draining	117
3.55	Fuel filter: renewing	118
3.56	Fuel tank: adding fuel additive	121
3.57	Reducing agent (AdBlue®): filling up tank completely	122
3.58	Body: checking vehicle paintwork for damage and corrosion from below and with bonnet, rear lid and doors open	126
3.59	Road test	126
3.60	Stock vehicles: observing measures specified in Maintenance table for stock vehicles (see "Before handing vehicle over to customer")	127
3.61	Rear final drive: changing gear oil	127
3.62	Rear final drive: changing ATF	128
3.63	Display instruments: setting language, time and date	128
3.64	Automatic gearbox (multitronic): changing ATF	128
3.65	Automatic gearbox (tiptronic): changing ATF fluid	128
3.66	Dual clutch gearbox (S tronic): changing ATF	128
3.67	Dual clutch gearbox (S tronic): changing ATF and renewing exchangeable ATF filter	128
3.68	Interior mirror: calibrating compass	128
3.69	Poly V-belt for supercharger with charge air coolers: renewing	129
3.70	Poly V-belts for ancillaries: renewing	129
3.71	Poly V-belts for ancillaries and pulleys for coolant pump and power steering pump: renewing	129
3.72	Instrument cluster: resetting driver information system	129
3.73	Toothed belt for camshaft drive: renewing	129
3.74	Toothed belt for camshaft drive, and drive sprockets for camshaft, crankshaft and high-pressure pump: renewing	129
3.75	Toothed belt for camshaft drive and tensioning roller: renewing	130
3.76	Poly V-belts for ancillaries and pulley for power steering pump: renewing	130

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 General information

(AIGG000682; Edition 06.2015)

Change history ➔ [page 1](#)

Overview of engines ➔ [page 1](#)

Engine number ➔ [page 6](#)

Vehicle identification number ➔ [page 9](#)

Vehicle data sticker ➔ [page 9](#)

Warnings for high-voltage vehicles ➔ [page 10](#)

1.1 --- Change history ---

N o.	Date	Chapter	Changes made
5	29.06.2015	Fuel filter: renewing ➔ page 118	Water separator added to fuel filter
		Fuel filter: draining ➔ page 117	Chapter added
4	26.05.2015	Battery: connecting to a stationary battery charging unit for sustained charging ➔ page 39	Procedure for A7 modified
		Engine, gearbox, final drive and steering: checking for leaks and damage ➔ page 60	Procedure modified to include: Removing noise insulation for certain service procedures
		Headlights: checking for correct adjustment ➔ page 72	List of required tools modified
		Cooling system: checking anti-freeze and coolant level, and correcting if necessary ➔ page 102	Note added warning against over-filling coolant expansion tank
		Fuel tank: adding fuel additive ➔ page 121	Procedure modified
		Dual clutch gearbox (S tronic): changing ATF fluid ➔ page 128	Chapter added
3	02.03.2015	Rear spoiler hinges: lubricating ➔ page 68	New chapter



Note

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

For greater clarity, only the last three updates to the document are listed.

1.2 Overview of engines

Petrol engines ➔ [page 1](#)

Diesel engines ➔ [page 4](#)

1.2.1 Petrol engines

Engine code	Engine type/ number of cylinders	Capacity [ltr.]	Injection system	Power output [kW] (rpm)	Torque [Nm] (rpm)	Camshaft drive	Stroke [mm]	Bore [mm]	Compression ratio [:1]
CAEB	4-cyl. in-line	2.0	TFSI	155 (4300-6000)	350 (1500-4200)	Timing chain	92.8	82.5	9.6
CAED	4-cyl. in-line	2.0	TFSI	162	350	Timing chain	92.8	82.5	9.6



Engine code	Engine type/ number of cylinders	Capacity [ltr.]	Injection system	Power output [kW] (rpm)	Torque [Nm] (rpm)	Camshaft drive	Stroke [mm]	Bore [mm]	Compression ratio [∶1]
				(4300-6000)	(3000-5000)				
CDNB	4-cyl. in-line	2.0	TFSI	132 (4000-6000)	320 (1500-3900)	Timing chain	92.8	82.5	9.6
CDZA	4-cyl. in-line	2.0	TFSI	132 (4200-6000)	320 (1500-4000)	Timing chain	92.8	82.5	9.6
CEUC	V8	4.0	TFSI	309 (5500-6400)	550 (1400-5200)	Timing chain	89.0	84.5	10.1
CGWB	V6	3.0	TFSI	220 (5250-6500)	440 (2900-4500)	Timing chain	89.0	84.5	10.5
CGWD	V6	3.0	TFSI	228 (5500-6500)	440 (2900-4500)	Timing chain	89.0	84.5	10.5
CGXB	V6	3.0	TFSI	228 (5500-6500)	440 (2900-4500)	Timing chain	89.0	84.5	10.5
CHJA	4-cyl. in-line	2.0	TFSI hybrid	155 (4200-6000)	350 (1500-4200)	Timing chain	92.8	82.5	9.6
CHMA	V6	3.0	TFSI	220 (5500)	440 (1600)	Timing chain	89.0	84.5	10.5
CHVA	V6	2.8	FSI	150 (5250-6500)	280 (3000-5000)	Timing chain	82.4	84.5	12.0
CLXA	V6	2.5	FSI	140 (5500)	250 (3250-4750)	Timing chain	82.4	80.2	12.3
CLXB	V6	2.5	FSI	150 (6000)	250 (3250-4750)	Timing chain	82.4	80.2	12.3
CNYA	V6	2.8	FSI	150 (5750-6800)	280 (3250-5000)	Timing chain	82.4	84.5	12.0
CNYB	V6	2.8	FSI	162 (5750-6800)	280 (3250-5000)	Timing chain	82.4	84.5	12.0

Engine code	Engine type/ number of cylinders	Capacity [ltr.]	Injection system	Power output [kW] (rpm)	Torque [Nm] (rpm)	Camshaft drive	Stroke [mm]	Bore [mm]	Compression ratio [∶1]
CRDB	V8	4.0	TFSI	412 (5700-6600)	700 (1750-5500)	Timing chain	89.0	84.5	9.3
CREC	V6	3.0	TFSI	245 (5300-6500)	440 (2900-5300)	Timing chain	89.0	84.5	10.8
CTDB	V6	3.0	TFSI	200 (4850-6500)	400 (2500-4850)	Timing chain	89.0	84.5	10.8
CTGB	V8	4.0	TFSI	320 (5100-6400)	550 (1500-5000)	Timing chain	89.0	84.5	10.1
CTGE	V8	4.0	TFSI	331 (5800-6400)	550 (1400-5700)	Timing chain	89.0	84.5	10.1
CTTA	V6	3.0	TFSI	228 (5500-6500)	440 (2900-4500)	Timing chain	89.0	84.5	10.5
CTUA	V6	3.0	TFSI	228 (5500-6500)	440 (2900-4500)	Timing chain	89.0	84.5	10.5
CVPA	V6	2.8	FSI	162 (5750-6500)	280 (3000-5000)	Timing chain	82.4	84.5	12.0
CWUB	V8	4.0	TFSI	412 (5700-6600)	700 (1750-5500)	Timing chain	89.0	84.5	9.3
CWUC	V8	4.0	TFSI	445 (5900-6600)	750 (1750-5800)	Timing chain	89.0	84.5	9.3
CYGA	4-cyl. in-line	1.8	TFSI	140 (4200-6200)	320 (1400-4100)	Timing chain	84.1	82.5	9.6
CYNB	4-cyl. in-line	2.0	TFSI	185 (4900-5900)	370 (1600-4700)	Timing chain	92.8	82.5	9.6
CYPA	4-cyl. in-line	2.0	TFSI	185 (4900-5900)	370 (1600-4700)	Timing chain	92.8	82.5	9.6

Protected by copyright. No reproduction for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Engine code	Engine type/ number of cylinders	Capacity [ltr.]	Injection system	Power output [kW] (rpm)	Torque [Nm] (rpm)	Camshaft drive	Stroke [mm]	Bore [mm]	Compression ratio [∶1]
CYPB	4-cyl. in-line	2.0	TFSI	183 (4900-5900)	370 (1600-4700)	Timing chain	92.8	82.5	9.6

1.2.2 Diesel engines

Engine code	Engine type/ number of cylinders	Capacity [ltr.]	Injection system	Power output [kW] (rpm)	Torque [Nm] (rpm)	Camshaft drive	Stroke [mm]	Bore [mm]	Compression ratio [∶1]
CDUC	V6	3.0	TDI common rail	180 (4000-4500)	500 (1400-3250)	Timing chain	91.4	83.0	16.8
CDUD	V6	3.0	TDI common rail	180 (4000-4500)	580 (1750-2500)	Timing chain	91.4	83.0	16.8
CGLC	4-cyl. in-line	2.0	TDI common rail	130 (4200)	380 (1750-2500)	Toothed belt	95.5	81.0	16.0
CGLD	4-cyl. in-line	2.0	TDI common rail	120 (4200)	380 (1750-2500)	Toothed belt	95.5	81.0	16.0
CGLE	4-cyl. in-line	2.0	TDI common rail	100 (4200)	350 (1750-2500)	Toothed belt	95.5	81.0	16.0
CGQB	V6	3.0	TDI common rail	230 (3900-4500)	650 (1450-2800)	Timing chain	91.4	83.0	16.5
CKVB	V6	3.0	TDI common rail	180 (4000-4500)	500 (1400-3250)	Timing chain	91.4	83.0	16.8
CKVC	V6	3.0	TDI common rail	180 (4000-4500)	580 (1750-2500)	Timing chain	91.4	83.0	16.8
CLAA	V6	3.0	TDI common rail	150 (3250-4500)	450 (1250-3000)	Timing chain	91.4	83.0	16.8
CLAB	V6	3.0	TDI common rail	150 (3750-4500)	400 (1250-3500)	Timing chain	91.4	83.0	16.8

Engine code	Engine type/ number of cylinders	Capacity [ltr.]	Injection system	Power output [kW] (rpm)	Torque [Nm] (rpm)	Camshaft drive	Stroke [mm]	Bore [mm]	Compression ratio [∶1]
CMGB	4-cyl. in-line	2.0	TDI common rail	130 (4200)	380 (1750-2500)	Toothed belt	95.5	81.0	16.0
CNHA	4-cyl. in-line	2.0	TDI common rail	140 (4000)	400 (1900-3500)	Toothed belt	95.5	81.0	15.5
CPNB	V6	3.0	TDI common rail	176 (4000)	580 (2100)	Timing chain	91.4	83.0	16.8
CRTD	V6	3.0	TDI common rail	200 (4000)	580 (1700-2750)	Timing chain	91.4	83.0	16.0
CRTE	V6	3.0	TDI common rail	160 (4000)	500 (1700-2750)	Timing chain	91.4	83.0	16.0
CRTF	V6	3.0	TDI common rail	155 (4000)	500 (1700-2750)	Timing chain	91.4	83.0	16.0
CSUD	4-cyl. in-line	2.0	TDI common rail	110 (3500-4000)	350 (1500-3000)	Toothed belt	95.5	81.0	16.2
CSUE	4-cyl. in-line	2.0	TDI common rail	100 (2750-4400)	350 (1500-2750)	Toothed belt	95.5	81.0	16.2
CTCB	V6	3.0	TDI common rail	155 (4000)	400 (1250-3500)	Timing chain	91.4	83.0	16.8
CTCC	V6	3.0	TDI common rail	160 (4000)	400 (1250-3500)	Timing chain	91.4	83.0	16.8
CVUA	V6	3.0	TDI common rail	235 (4250)	650 (1450-2800)	Timing chain	91.4	83.0	15.5
CVUB	V6	3.0	TDI common rail	240 (4250)	650 (1450-2800)	Timing chain	91.4	83.0	15.5
CZJA	4-cyl. in-line	2.0	TDI common rail	140 (4200)	400 (1750-4200)	Toothed belt	95.5	81.0	15.5

Engine code	Engine type/ number of cylinders	Capacity [ltr.]	Injection system	Power output [kW] (rpm)	Torque [Nm] (rpm)	Camshaft drive	Stroke [mm]	Bore [mm]	Compression ratio [:1]
CZVA	V6	3.0	TDI common rail	140 (4000)	500 (1250-3200)	Timing chain	91.4	83.0	16.0
CZVB	V6	3.0	TDI common rail	160 (4000)	400 (1250-3200)	Timing chain	91.4	83.0	16.0
CZVC	V6	3.0	TDI common rail	155 (4000)	500 (1250-3200)	Timing chain	91.4	83.0	16.0
CZVD	V6	3.0	TDI common rail	155 (4000)	400 (1250-3200)	Timing chain	91.4	83.0	16.0
CZVE	V6	3.0	TDI common rail	140 (3500-5000)	400 (1250-3250)	Timing chain	91.4	83.0	16.0
CZVF	V6	3.0	TDI common rail	140 (2750-5000)	500 (1250-2500)	Timing chain	91.4	83.0	16.0

1.3 Engine number



Note

The engine number consists of the engine code letters (3 or 4 characters) and the serial number.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/2.0 ltr. TFSI hybrid
⇒ [page 7](#)

6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI ⇒ [page 7](#)

6-cyl. petrol engine 3.0 ltr. TFSI ⇒ [page 8](#)

8-cyl. petrol engine 4.0 ltr. TFSI ⇒ [page 8](#)

4-cyl. diesel engine 2.0 ltr. TDI ⇒ [page 8](#)

6-cyl. diesel engine 3.0 ltr. TDI ⇒ [page 8](#)

1.3.1 4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/ 2.0 ltr. TFSI hybrid



DANGER!


Risk of fatal injury if high-voltage components are damaged.

- ◆ *Observe warnings for high-voltage system:*
- ◆ *Handling high-voltage wires ⇒ [page 12](#).*
- ◆ *For work in the vicinity of high-voltage components ⇒ [page 11](#).*

The engine number is stamped on the left side at the joint between the engine and the gearbox -arrow-.

The engine number is also given on the sticker on the toothed belt cover (top).

In addition, the engine code letters are listed on the vehicle data sticker ⇒ [page 9](#).




1.3.2 6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI

The engine number is stamped on the left side at the joint between the engine and the gearbox -arrow-.

The engine number is also given on the sticker on the toothed belt cover (top).

In addition, the engine code letters are listed on the vehicle data sticker ⇒ [page 9](#).




1.3.3 6-cyl. petrol engine 3.0 ltr. TFSI

The engine number is stamped on the left side at the joint between the engine and the gearbox -arrow-.

The engine number is also given on the sticker on the toothed belt cover (top).

In addition, the engine code letters are listed on the vehicle data sticker ➔ [page 9](#) .



1.3.4 8-cyl. petrol engine 4.0 ltr. TFSI

The engine number is stamped on the left side at the joint between the engine and the gearbox -arrow-.

The engine number is also given on the sticker on the toothed belt cover (top) -arrow A-.

In addition, the engine code letters are listed on the vehicle data sticker ➔ [page 9](#) .




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability for the content of this document. Copyright © Audi AG.

1.3.5 4-cyl. diesel engine 2.0 ltr. TDI

The engine number is stamped on the left side at the joint between the engine and the gearbox -arrow-.

The engine number is also given on the sticker on the toothed belt cover (top).

In addition, the engine code letters are listed on the vehicle data sticker ➔ [page 9](#) .




1.3.6 6-cyl. diesel engine 3.0 ltr. TDI

The engine number is stamped on the left side at the joint between the engine and the gearbox -arrow-.

The engine number is also given on the sticker on the toothed belt cover (top).

In addition, the engine code letters are listed on the vehicle data sticker ➔ [page 9](#) .



1.4 Vehicle identification number

Depending on the equipment and country-specific version, the vehicle identification number is located:

- ◆ Optional: In the MMI under »Car systems«
- ◆ At the bottom left edge of the windscreen
- ◆ On the right side of the engine compartment under a cover
- ◆ On the bulkhead of the engine compartment
- ◆ On the vehicle data sticker ➔ [page 9](#)

The vehicle identification number consists of the following:

W A U	Z Z Z	4 G	Z	B	A / N	0 0 0 2 3 4
Manufacturer's mark	Filler characters	Type	Filler characters	Model year	Production location	Serial number

1.5 Vehicle data sticker

The vehicle data sticker is located:


- ◆ In the Service Schedule
- ◆ In the area of the spare wheel well under the floor covering -arrow-



The vehicle data sticker contains the following vehicle data:

- 1 - Vehicle identification number
- 2 - Vehicle model, manufacturer's code, engine type and power output, production month and year
- 3 - Engine and gearbox code letters (not specified on some export models)
- 4 - Paint number, interior equipment number
- 5 - Numbers for optional extras
- 6 - Fuel consumption: urban, extra urban, combined, CO2 (not specified on some export models)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without permission by AUDI AG. AUDI AG does not accept any liability with respect to the correctness of information in this document. Copyright © AUDI AG.



1.6 Warnings for high-voltage vehicles

Overview of high-voltage components and wires ➔ [page 10](#)

Working in the vicinity of high-voltage components ➔ [page 11](#)

Handling high-voltage wires ➔ [page 12](#)

Work that must be performed with the ignition switched on
➔ [page 13](#)

Work that must be performed with the ignition switched off
➔ [page 13](#)

1.6.1 Overview of high-voltage components and wires

The high-voltage system of the Audi A6 is comprised of the following components:

1 - Combustion engine

2 - High-voltage wire for electrical air conditioner compressor P3-

❑ Red warning label

3 - Power and control electronics for electric drive - JX1-

- ❑ Electric drive control unit - J841-
- ❑ Voltage converter - A19-
- ❑ DC/AC converter for drive motor - A37-
- ❑ Red warning label
- ❑ Coded high-voltage connections

4 - Drive battery - A2-

- ❑ Maintenance connector for high-voltage system - TW-
- ❑ Red warning label and battery warning label
- ❑ Coded high-voltage connections

5 - Air duct for cooling drive battery - A2-


6 - Cooling module for drive battery - A2-

7 - High-voltage system wiring junction - TV1-

8 - Air supply duct for cooling drive battery - A2-

9 - High-voltage wire for hybrid battery - PX1-

- ❑ High-voltage wiring harness for high-voltage battery, positive terminal - P1- (red coloured ring)
- ❑ High-voltage wiring harness for hybrid battery, negative terminal - P2- (brown coloured ring)
- ❑ Coding of high-voltage connections to drive battery - A2-
- ❑ Coding of high-voltage connections to power and control electronics for electric drive - JX1-



10 - High-voltage wiring harness for drive motor - PX2-

- ☐ High-voltage wire 1 for drive motor - P4- (U) blue coloured ring/coding lug on right side
- ☐ High-voltage wire 1 for drive motor - P5- (V) green coloured ring/coding lug on left side
- ☐ High-voltage wire 1 for drive motor - P6- (W) violet coloured ring/two coding lugs
- ☐ Coding of high-voltage connections to power and control electronics for electric drive - JX1-
- ☐ Coding of high-voltage connections to electric drive motor - V141-

11 - Electric drive motor - V141-

- ☐ Red warning label
- ☐ Coded high-voltage connections

12 - Electrical air conditioner compressor - V470-

- ☐ Coding of high-voltage connection: red coloured ring

1.6.2 Working in the vicinity of high-voltage components



DANGER!

Risk of fatal injury if high-voltage components are damaged.

Observe the following when working in the vicinity of high-voltage components or wiring:

It is not permitted to use cutting or forming tools, other sharp-edged tools or heat sources such as welding, brazing, soldering, hot air or thermal bonding equipment.

- ◆ **Before starting work, visually inspect the high-voltage components in the areas involved.**
- ◆ **Before working in the engine compartment, visually inspect the power and control electronics for electric drive - JX1- , electric drive motor - V141- , air conditioner compressor - V470- and high-voltage wiring.**
- ◆ **Before working on the vehicle underbody, visually inspect the high-voltage wiring and covers.**
- ◆ **Before working on the rear section of the vehicle, visually inspect the high-voltage wiring and the electro-box with the maintenance connector for high-voltage system - TW - .**
- ◆ **Visually inspect all potential equalisation lines.**

Check the following when making the visual inspection:

- ◆ **There must be no external damage on any component.**
- ◆ **The insulation of the high-voltage wiring and potential equalisation lines must not be damaged.**
- ◆ **There must be no unusual deformation of the high-voltage wiring.**
- ◆ **All high-voltage components must be identified by a red warning sticker.**



Note

- ◆ *Certain qualifications are required to perform different types of work on high-voltage vehicles ⇒ Basic information on high-voltage vehicles; Rep. gr. 00; Qualification of internal/external personnel .*
- ◆ *Note distinguishing features of Audi high-voltage vehicles, description of high-voltage technology etc. ⇒ Basic information on high-voltage vehicles; Rep. gr. 00; Distinguishing features of Audi high-voltage vehicles .*
- ◆ *Overview of high-voltage components and wires ⇒ [page 10](#) .*

1.6.3 Handling high-voltage wires



WARNING

Handling high-voltage wires:

- *Do not support yourself or tools on high-voltage wiring or associated components --> this can damage the insulation.*
- *High-voltage wiring must not be excessively bent or kinked --> this can damage the insulation.*
- *The round high-voltage connectors are colour-coded with an external coloured ring and are provided with mechanical coding or guide lugs. It is important to observe this coding when joining up the round high-voltage connectors, otherwise the connectors can be damaged.*



Note

- ◆ *Certain qualifications are required to perform different types of work on high-voltage vehicles ⇒ Basic information on high-voltage vehicles; Rep. gr. 00; Qualification of internal/external personnel .*
- ◆ *Note distinguishing features of Audi high-voltage vehicles, description of high-voltage technology etc. ⇒ Basic information on high-voltage vehicles; Rep. gr. 00; Distinguishing features of Audi high-voltage vehicles .*
- ◆ *Overview of high-voltage components and wires ⇒ [page 10](#) .*

1.6.4 Work that must be performed with the ignition switched on



DANGER!

When working on a vehicle with the ignition switched on or while the drive system is active, the engine can start unexpectedly and exhaust fumes can cause a health hazard in closed rooms. Moving parts can trap or draw in parts of the body and/or clothing (safety hazard).

Before switching on the ignition, perform the following steps:

- ◆ *Move selector lever to position P*
- ◆ *Activate parking brake*
- ◆ *Switch off ignition*
- ◆ *Open bonnet*
- ◆ *Connect battery charger (e.g. charger - VAS 5095A-) to jump-start connections of 12 V electrical system*
- ◆ *Switch on ignition.*



Note

- ◆ *Certain qualifications are required to perform different types of work on high-voltage vehicles ⇒ Basic information on high-voltage vehicles; Rep. gr. 00; Qualification of internal/external personnel .*
- ◆ *Note distinguishing features of Audi high-voltage vehicles, description of high-voltage technology etc. ⇒ Basic information on high-voltage vehicles; Rep. gr. 00; Distinguishing features of Audi high-voltage vehicles .*
- ◆ *Overview of high-voltage components and wires ⇒ [page 10](#) .*

1.6.5 Work that must be performed with the ignition switched off



WARNING

Safety hazard: the engine can start unexpectedly.

Before carrying out general work on a vehicle with high-voltage electrical system, switch off the ignition and remove the ignition key from the vehicle.



- ts and wires** **→ page 10**

2 Preparations

Vehicle: raising ⇒ [page 15](#)

Engine cover panel: removing and installing ⇒ [page 17](#)

Noise insulation: removing and installing ⇒ [page 21](#)

Window regulators: activating automatic open/close function
⇒ [page 23](#)

Vehicle diagnostic tester: connecting ⇒ [page 23](#)

2.1 Vehicle: raising




Caution

Risk of damage to vehicle due to incorrect use of lifting platform.

- ◆ *Do not exceed the permissible lifting capacity of the lifting platform.*
- ◆ *The vehicle should be lifted only at the points shown in the illustration.*
- ◆ *Position support plates so that they are aligned centrally below the lifting points.*
- ◆ *Ensure sufficient clearance between low-mounted vehicle components and the lifting platform.*


Procedure:

- For vehicles with adaptive air suspension: Activate jacking mode before lifting vehicle ⇒ [page 16](#).
- Applies to RS models: Pull side member extension covers downwards -arrow- and remove.



Protected by copyright. Copying for private or commercial purposes is prohibited unless permitted in writing by Audi AG. Audi AG does not guarantee, in whole or in part, with respect to the correctness of information in this document compiled by Audi AG.

- Front: Position support plates of lifting platform under plastic mountings -arrow- on underside of side member trim.




- Rear: Position support plates of lifting platform under plastic mountings -arrow- on underside of side member trim.



Note

The location of the lifting points is indicated by markings stamped on the side member trim.

Protected by copyright. Copying for private or commercial purposes, in particular for reproduction, is prohibited without the prior written permission of AUDI AG. AUDI AG is not responsible for any errors or omissions with respect to the correctness of information in this document. Copyright by AUDI AG.



2.1.1 Activating jacking mode



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ Observe warnings for high-voltage system:
- ◆ For work that must be performed with the ignition switched on ➔ [page 13](#).

Procedure:

- Switch on ignition and activate MMI.
- Press function selector button **CAR**.
- Under »Systems«, navigate through following menu structure:
 - ◆ adaptive air suspension
 - ◆ SETUP

- Use MMI rotary pushbutton to select “Jacking mode” and set to “on”.



Note

- ♦ *Jacking mode is switched off again automatically once a speed higher than 15 km/h is reached.*
- ♦ *If jacking mode is activated for a longer period of time, the pressure in the suspension struts may dissipate, thereby lowering the vehicle. If necessary, start the engine briefly to reactivate jacking mode.*

2.2 Engine cover panel: removing and installing

4-cyl. petrol engine 1.8 ltr. TFSI ➔ [page 17](#)

4-cyl. petrol engine 2.0 ltr. TFSI (version 1) ➔ [page 18](#)

4-cyl. petrol engine 2.0 ltr. TFSI/2.0 ltr. TFSI hybrid (version 2)
➔ [page 18](#)

6-cyl. petrol engine 2.5 ltr. FSI/2.8 ltr. FSI/3.0 ltr. TFSI (version 1)
➔ [page 18](#)

6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI (version 2) ➔ [page 19](#)

6-cyl. petrol engine 3.0 ltr. TFSI (version 2) ➔ [page 19](#)

8-cyl. petrol engine 4.0 ltr. TFSI ➔ [page 20](#)

4-cyl. diesel engine 2.0 ltr. TDI ➔ [page 20](#)

6-cyl. diesel engine 3.0 ltr. TDI (version 1) ➔ [page 20](#)

6-cyl. diesel engine 3.0 ltr. TDI (version 2) ➔ [page 21](#)

6-cyl. diesel engine 3.0 ltr. TDI (version 3) ➔ [page 21](#)


2.2.1 4-cyl. petrol engine 1.8 ltr. TFSI

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.

Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



2.2.2 4-cyl. petrol engine 2.0 ltr. TFSI (version 1)

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.


Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



Note

There is more than one version of the engine cover panel for the 4-cylinder 2.0 ltr. TFSI petrol engine ➔ [page 18](#).



2.2.3 4-cyl. petrol engine 2.0 ltr. TFSI/2.0 ltr. TFSI hybrid (version 2)

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.


Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



Note

There is more than one version of the engine cover panel for the 4-cylinder 2.0 ltr. TFSI petrol engine ➔ [page 18](#).



2.2.4 6-cyl. petrol engine 2.5 ltr. FSI/2.8 ltr. FSI/3.0 ltr. TFSI (version 1)

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.

Procedure for installing:


- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



Note

♦ *There is more than one version of the engine cover panel for the 6-cylinder 2.5 ltr. FSI/2.8 ltr. FSI petrol engine ➔ [page 19](#).*

♦ *There is more than one version of the engine cover panel for the 6-cylinder 3.0 ltr. TFSI petrol engine ➔ [page 19](#).*



2.2.5 6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI (version 2)

Procedure for removing:


- Carefully pull engine cover panels off retaining pins one after another -arrows-.

Procedure for installing:

- Position engine cover panels on retaining pins and then use your hands to press it onto retaining pins, one after the other.



There is more than one version of the engine cover panel for the 6-cylinder 2.5 ltr. FSI/2.8 ltr. FSI petrol engine ➔ [page 18](#) .



2.2.6 6-cyl. petrol engine 3.0 ltr. TFSI (version 2)

Procedure for removing:

- Carefully pull engine cover panels -1- and -2- off retaining pins one after another.

Procedure for installing:

- Position engine cover panels on retaining pins and then use your hands to press it onto retaining pins, one after the other.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG



There is more than one version of the engine cover panel for the 6-cylinder 3.0 ltr. TFSI petrol engine ➔ [page 18](#) .



2.2.7 8-cyl. petrol engine 4.0 ltr. TFSI


Procedure for removing:

- Carefully pull engine cover panel off rear retaining pins -1-.
- Carefully pull engine cover panel off front retaining pins -2-.

Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.

Protected by copyright. Copying for private or commercial purposes is permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document.




2.2.8 4-cyl. diesel engine 2.0 ltr. TDI

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.

Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



2.2.9 6-cyl. diesel engine 3.0 ltr. TDI (version 1)

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.


Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



Note

There is more than one version of the engine cover panel for the 6-cylinder 3.0 ltr. TDI diesel engine ➔ [page 21](#).



2.2.10 6-cyl. diesel engine 3.0 ltr. TDI (version 2)

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.


Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



Note

There is more than one version of the engine cover panel for the 6-cylinder 3.0 ltr. TDI diesel engine ➔ [page 21](#).



2.2.11 6-cyl. diesel engine 3.0 ltr. TDI (version 3)

Procedure for removing:

- Carefully pull engine cover panel off retaining pins one after another -arrows-.


Procedure for installing:

- Position engine cover panel on retaining pins and then use your hands to press it onto retaining pins, one after the other.



Note

There is more than one version of the engine cover panel for the 6-cylinder 3.0 ltr. TDI diesel engine ➔ [page 20](#).



2.3 Noise insulation: removing and installing



DANGER!

Risk of fatal injury if high-voltage components are damaged.

- ◆ Observe warnings for high-voltage system:
- ◆ For work in the vicinity of high-voltage components ➔ [page 12](#).

Noise insulation (front) ➔ [page 21](#)

Noise insulation (rear) ➔ [page 22](#)

2.3.1 Noise insulation (front)

Special tools and workshop equipment required

- ◆ Torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:


Component/fastener	[Nm]
Bolt M8 -2-	20
Bolt M6 -3-	3.5

Procedure for removing:

- Remove bolts -1- and -2-.
- Unscrew quick-release fasteners -3- and -4-.
- Pull noise insulation -5- towards rear out of bottom section of bumper cover and detach.


Procedure for installing:

Install in reverse sequence. Note tightening torques (see table of tightening torques for installation ➔ [page 22](#)).



Note

- ◆ Ensure that you feel the quick-release fasteners engage when installing.
- ◆ On vehicles with supplementary heater, opening of exhaust pipe must be routed vertically through grommet in noise insulation.



2.3.2 Noise insulation (rear)

Special tools and workshop equipment required

- ◆ Torque screwdriver - V.A.G 1624- , measuring range 1 to 5 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Bolt M6 -1-	3.6

Procedure for removing:

- Remove bolts -1- at connection to noise insulation (front).
- Unscrew quick-release fasteners -2- and -4-.
- Pull noise insulation -3- towards rear out of noise insulation (front) and detach.


Procedure for installing:

Install in reverse sequence. Note tightening torques (see table of tightening torques for installation ➔ [page 22](#)).



Note

Ensure that you feel the quick-release fasteners engage when installing.



2.4 Window regulators: activating automatic open/close function



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ Observe warnings for high-voltage system:
- ◆ For work that must be performed with the ignition switched on ➔ [page 13](#) .

If the vehicle battery was disconnected, the automatic open/close function for the electric windows must be reactivated.

Procedure:

- Pull up on window regulator switch until windows are completely closed.
- Release switch and pull on it again for at least one second.
- Repeat procedure with all window regulators.

2.5 Vehicle diagnostic tester: connecting



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ Observe warnings for high-voltage system:
- ◆ For work that must be performed with the ignition switched on ➔ [page 13](#) .

Special tools and workshop equipment required

◆ Diagnosis system - VAS 6160 A-



◆ Remote diagnosis head - VAS 5054A-

◆ Or: Diagnosis interface - VAS 5055-

Procedure:

- Plug connector for remote diagnosis head - VAS 5054A- into diagnostic connection in vehicle.
- Switch on diagnostic system - VAS 6160 A- .
- Switch on ignition.
- Follow the menu on the screen to start the desired functions.



Protected by copyright. Copying for private or commercial use is not permitted unless authorised by AUDI AG. Audi AG is not responsible with respect to the correctness of information in this document.



Protected by copyright. Copying for private use without express permission is prohibited.
Reproduction of this manual for other than private use without express permission is prohibited.
Audi AG, Ingolstadt, Germany. Copyright 2015 Audi AG.

3 Maintenance

Rear final drive: changing gear oil ⇒ [page 127](#)

Rear final drive: changing ATF ⇒ [page 128](#)

Display instruments: setting language, time and date
⇒ [page 128](#)

Automatic gearbox (multitronic): changing ATF ⇒ [page 128](#)

Automatic gearbox (tiptronic): changing ATF fluid ⇒ [page 128](#)

Battery: checking that battery and battery cables are securely fitted ⇒ [page 33](#)

Battery: checking electrolyte level ⇒ [page 36](#)

Battery: reading out status and sending diagnostic log
⇒ [page 31](#)

Components of front and rear axles: checking play, secure attachment and protective boots ⇒ [page 56](#)

Front passenger's airbag: checking key switch on / off and setting to "on" ⇒ [page 76](#)

Tyres: checking tyre pressures and adjusting if necessary
⇒ [page 51](#)

Tyres: checking condition and wear pattern, and checking and recording tread depth ⇒ [page 50](#)

Tool kit: checking that all components necessary in the event of a breakdown are present ⇒ [page 53](#)

Brake system: checking condition of brake hoses, and checking that caps are fitted on bleeder screws ⇒ [page 48](#)

Brake pads: checking thickness ⇒ [page 49](#)

Brake fluid: checking fluid level ⇒ [page 48](#)

Brake fluid: changing ⇒ [page 43](#)

Roof insert - panorama sunroof: cleaning and lubricating
⇒ [page 64](#)

Roof insert - sliding/tilting sunroof: cleaning and lubricating
⇒ [page 61](#)

Diesel particulate filter: reading out ash deposit volume
⇒ [page 28](#)

Dual clutch gearbox (S tronic): changing ATF fluid ⇒ [page 128](#)

Dual clutch gearbox (S tronic): changing ATF and renewing exchangeable ATF filter ⇒ [page 128](#)

Event memory: reading out and erasing ⇒ [page 29](#)

Headlights and reversing lights, side lights, number plate lights, turn signals, hazard warning lights: checking operation
⇒ [page 73](#)

Vehicle keys: checking operation and recording number of keys given to customer ⇒ [page 78](#)

Bonnet arrester hook: lubricating ⇒ [page 68](#)

Suspension struts on front and rear axle: removing locking elements ⇒ [page 54](#)

Glove box light, interior lighting and reading light: checking operation ⇒ [page 75](#)

Interior mirror: calibrating compass ⇒ [page 128](#)

Body: checking vehicle paintwork for damage and corrosion from below and with bonnet, rear lid and doors open ⇒ [page 126](#)

Poly V-belt for supercharger with charge air coolers: renewing ⇒ [page 129](#)

Poly V-belts for ancillaries and for pulleys for coolant pump and power steering pump: renewing ⇒ [page 129](#)

Poly V-belts for ancillaries and pulley for power steering pump: renewing ⇒ [page 130](#)

Poly V-belts for ancillaries: renewing ⇒ [page 129](#)

Poly V-belts for ancillaries: checking ⇒ [page 92](#)

Luggage compartment lighting: checking operation ⇒ [page 74](#)

Instrument cluster: resetting driver information system ⇒ [page 129](#)

Instrument cluster: checking warning lamps ⇒ [page 77](#)

Fuel tank: adding fuel additive ⇒ [page 121](#)

Fuel filter: draining ⇒ [page 117](#)

Fuel filter: renewing ⇒ [page 118](#)

Cooling system: checking anti-freeze and coolant level, and correcting if necessary ⇒ [page 102](#)

Air cleaner: renewing filter element and cleaning housing ⇒ [page 105](#)

Engine, gearbox, final drive and steering: checking for leaks and damage ⇒ [page 60](#)

Engine oil: draining ⇒ [page 79](#)

Engine oil: extracting ⇒ [page 81](#)

Engine oil: renewing oil filter ⇒ [page 82](#)

Engine oil: filling up ⇒ [page 89](#)

Engine oil: checking oil level and correcting if necessary ⇒ [page 90](#)

Battery: connecting to a stationary battery charging unit for sustained charging ⇒ [page 39](#)

Road test ⇒ [page 126](#)

Wheel bolts: tightening to specified torque ⇒ [page 54](#)

Reducing agent (AdBlue®): filling up tank completely ⇒ [page 122](#)

Tyre Pressure Loss Indicator: storing changed tyre pressures ⇒ [page 52](#)

Tyre repair kit: checking that set is complete, and checking and recording expiry date ⇒ [page 53](#)

Rear spoiler hinges: lubricating ⇒ [page 68](#)

Windscreen/rear window washer system: checking spray pattern and adjusting if necessary ⇒ [page 69](#)

Wiper blades: checking for damage ⇒ [page 71](#)

Headlights: checking for correct adjustment ⇒ [page 72](#)

Headlight washer system: checking operation ⇒ [page 71](#)

Service interval display: resetting service ⇒ [page 30](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without the express consent of Audi AG. Audi AG does not guarantee the content and liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Seat belts: checking that retaining rivets are fitted, and checking locking action of automatic belt retractor ➔ [page 77](#)

Horn: checking operation ➔ [page 76](#)

Stock vehicles: observing measures specified in Maintenance table for stock vehicles (see "Before handing vehicle over to customer") ➔ [page 127](#)

Dust and pollen filter: renewing ➔ [page 115](#)

Dust and pollen filter: renewing preliminary filter ➔ [page 115](#)

Transport mode: deactivating ➔ [page 30](#)

Underbody: checking trim, wheel housing liners, side members and pipes/wiring for damage, and checking that they are properly secured ➔ [page 61](#)

First-aid kit: checking and recording expiry date ➔ [page 78](#)

Shipping mode: deactivating ➔ [page 31](#)

Warning triangle: checking availability ➔ [page 78](#)

Plenum chamber and water drains: checking for dirt
➔ [page 113](#)

Toothed belt for camshaft drive, and drive sprockets for camshaft, crankshaft and high-pressure pump: renewing ➔ [page 129](#)

Toothed belt for camshaft drive and tensioning roller: renewing
➔ [page 130](#)

Toothed belt for camshaft drive: renewing ➔ [page 129](#)

Spark plugs: renewing ➔ [page 93](#)

3.1 Diesel particulate filter: reading out ash deposit volume

Table of test values and procedure guidelines:

Engine	Engine code	Measured value designation for diagnostic tester	Maximum value for ash deposit
4-cyl. diesel engine 2.0 ltr. TDI	All	Particulate filter, oil ash deposit volume	Oil ash deposit volume: 175 ml
6-cyl. diesel engine 3.0 ltr. TDI	CVUA, CVUB	Particulate filter, oil ash deposit volume	Oil ash deposit volume: 240 ml
	CKVB, CKVC	Particulate filter, oil ash deposit volume	Oil ash deposit volume: 360 ml
	CDUC, CDUD, CLAA, CLAB	Particulate filter, oil ash deposit volume	Oil ash deposit volume: 370 ml
	CRTD, CRTE, CRTF, CTCB, CTCC	Particulate filter, oil ash deposit volume	Oil ash deposit volume: 380 ml
	CGQB	Particulate filter, oil ash deposit volume	Oil ash deposit volume: 420 ml


Procedure:

- Connect vehicle diagnostic tester ➔ [page 23](#) .
- Select **Diagnosis** mode and begin diagnosis.
- Perform vehicle identification.
- De-select "Working with Guided Fault Finding" by removing **v** and press **Apply**.
- Continue to follow instructions on screen.

- Switch to “Control units” tab.
- Select control unit “01 — Engine electronics” and carry out following functions via right mouse button:
 - ◆ Identify control unit
 - ◆ Guided Functions
 - ◆ 01 - Read measured values
- Select desired measured value (see table of test values and procedure guidelines ⇒ [page 28](#)) by entering ☐ and confirming with .
- Evaluate measured value and follow further instructions on screen.
- Perform the following measures according to the measured value:

Result:	Measure:
Measured value < critical value	Vehicle can be driven for a further 30,000 km (19,000 miles).
Measured value ≥ critical value	Renew diesel particulate filter and reset measured value to zero ⇒ Engine; Rep. gr. 26 ; Emission control system; Removing and installing particulate filter .

3.2 Event memory: reading out and erasing



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ Observe warnings for high-voltage system:
- ◆ For work that must be performed with the ignition switched on ⇒ [page 13](#) .

Procedure:

- Connect vehicle diagnostic tester ⇒ [page 23](#) .
- Select mode and begin diagnosis.
- Perform vehicle identification.
- Select “Working with Guided Fault Finding” by entering ☐ and press .

The control unit is then identified, and the event memory is interrogated. Observe notes and test conditions.

- Switch to “Control units” tab and call up “Event memory list” for an overview of all entries stored in event memory.
- Correct relevant faults and erase event memory.



Note

The event memory is erased automatically if the Guided Fault Finding is closed correctly.

3.3 Service interval display: resetting service



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ➔ [page 13](#).*

Procedure:

- Connect vehicle diagnostic tester ➔ [page 23](#).
- Select **Diagnosis** mode and begin diagnosis.
- Perform vehicle identification.
- De-select "Working with Guided Fault Finding" by removing **v** and press **Apply**.
- Switch to "Special functions" tab.
- Select service setting to be reset (e.g. "17 — Inspection").
- Start program by selecting **Carry out check**.
- Continue to follow instructions on screen.



Note

Please refer to the relevant Maintenance table for information on which service channel to reset and what data to enter.

3.4 Transport mode: deactivating



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ➔ [page 13](#).*

Procedure:

- Connect vehicle diagnostic tester ➔ [page 23](#).
- Select **Diagnosis** mode and begin diagnosis.
- Perform vehicle identification.
- De-select "Working with Guided Fault Finding" by removing **v** and press **Apply**.
- Switch to "Special functions" tab and select following program:
 - ◆ 19 - Activating / deactivating transport mode
- Start program by selecting **Carry out check**.
- Continue to follow instructions on screen.

 Note

- ◆ *The transport mode serves to maintain the vehicle's ability to start.*
- ◆ *When the vehicle is in transport mode, many functions, e.g. radio, are restricted or unavailable.*

3.5 Shipping mode: deactivating



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ➔ [page 13](#).*

Procedure:

- Connect vehicle diagnostic tester ➔ [page 23](#).
- Select **Diagnosis** mode and begin diagnosis.
- Perform vehicle identification.
- De-select "Working with Guided Fault Finding" by removing **v** and press **Apply**.
- Switch to "Special functions" tab and select following program:
 - ◆ 34 - Activating / deactivating shipping mode
- Start program by selecting **Carry out check**.
- Continue to follow instructions on screen.

 Note

Deactivating shipping mode may cause the height of the vehicle to drop.

3.6 Battery: reading out status and sending diagnostic log



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ➔ [page 13](#).*

Battery -A- ➔ [page 32](#)

Second battery -A1- ➔ [page 32](#)

3.6.1 Battery -A-

Procedure:

- Connect vehicle diagnostic tester ➔ [page 23](#) .
- Select **Diagnosis** mode and begin diagnosis.
- Perform vehicle identification.
- Select "Working with Guided Fault Finding" by entering **v** and press **Apply**.
- Switch to "Special functions" tab and select following program:
 - ◆ A - Battery check
- Start program by selecting **Carry out check**.
- Continue to follow instructions on screen.
- Use results of test to determine following measures:
- Switch to **Control units** tab.
- Press **X Diagnosis** button and close diagnosis program.
- Send off diagnosis log online.



Note

- ◆ A working network connection is necessary to send the diagnostic log file online.
- ◆ After the diagnosis is complete, you will receive confirmation that the test log was sent successfully.

Result on vehicle diagnostic test- Measure:
er:

"Battery OK"	No further measures necessary.
"Charge battery"	Charge battery ➔ Electrical system; Rep. gr. 27 ; Battery; Charging battery .
"Battery is no longer of the same quality as when shipped"	Renew battery after consulting with customer ➔ Electrical system; Rep. gr. 27 ; Battery; Removing and installing battery .

3.6.2 Second battery -A1-

Only applies to hybrid vehicles

Procedure:

- Connect vehicle diagnostic tester ➔ [page 23](#) .
- Select **Diagnosis** mode and begin diagnosis.
- Perform vehicle identification.
- Select "Working with Guided Fault Finding" by entering **v** and press **Apply**.
- Switch to "Special functions" tab and select following program:
 - ◆ A - second battery -A1-, check
- Start program by selecting **Carry out check**.
- Continue to follow instructions on screen.

- Use results of test to determine following measures:

Result on vehicle diagnostic test- Measure:
er:

"Battery OK"	No further measures necessary.
"Charge battery"	Charge battery ➔ Electrical system; Rep. gr. 27 ; Battery; Charging battery .
"Battery is no longer of the same quality as when shipped"	Renew battery after consulting with customer ➔ Electrical system; Rep. gr. 27 ; Battery; Removing and installing battery .

- Switch to **Control units** tab.
- Press **X Diagnosis** button and close diagnosis program.
- Send off diagnosis log online.



Note

- ◆ *A working network connection is necessary to send the diagnostic log file online.*
- ◆ *After the diagnosis is complete, you will receive confirmation that the test log was sent successfully.*

3.7 Battery: checking that battery and battery cables are securely fitted

All models except A6 hybrid ➔ [page 33](#)

A6 hybrid ➔ [page 34](#)

3.7.1 All models except A6 hybrid



WARNING

Risk of injury due to loose battery clamp on positive terminal.

- ◆ *Disconnect battery clamp from negative terminal and then tighten battery clamp on positive terminal.*

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Nut on battery clamp	4
Nut on accumulator	9
Bolt on retainer plate	18

The battery is located under the luggage compartment floor.

Requirements:

- Ignition switched off during test.



Removal steps:

- Lift luggage compartment floor and secure in position.
- Applies to vehicles with adaptive air suspension: Remove nuts -arrows- and move accumulator to side (leave lines -1- and solenoid valve block -2- connected).
- Take out tool kit box.
- Open battery terminal covers.

Procedure:

- Check by hand that battery terminal clamps are securely seated. If necessary, tighten nuts -1- and -2- to specified torque (see table of tightening torques for installation ➤ [page 33](#)).
- Check by hand that battery is securely installed. If necessary, tighten securing bolt -3- on retainer plate to specified torque (see table of tightening torques for installation ➤ [page 33](#)).

Install in reverse sequence. Note tightening torques (see table of tightening torques for installation ➤ [page 33](#)).



3.7.2 A6 hybrid



DANGER!

Risk of fatal injury if high-voltage components are damaged.

- ◆ Observe warnings for high-voltage system:
- ◆ Handling high-voltage wires ➤ [page 12](#) .
- ◆ For work in the vicinity of high-voltage components ➤ [page 11](#) .



WARNING

Risk of injury due to loose battery clamp on positive terminal.

- ◆ Disconnect battery clamp from negative terminal and then tighten battery clamp on positive terminal.

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Battery terminal clamp (battery -A-)	4
Battery terminal clamp (additional battery -A1-)	4

Component/fastener	[Nm]
Bolt on retainer plate (battery -A-)	9
Bolt on retainer plate (additional battery -A1-)	18

Battery -A- and second battery -A1- are located under the luggage compartment floor.

Requirements:


- Ignition switched off during test.

Removal steps:

- Remove luggage compartment floor covering ⇒ Trim, insulation; Rep. gr. 70 ; Removing and installing luggage compartment floor covering - Audi A6 hybrid .
- Move electrical wiring harness -1- clear.



- Unscrew bolts -2-.
- Release retainers -1- on both sides and disconnect exhaust air duct (front) -3- from battery cooling module.
- Lift air duct so that it is possible to check negative terminal of battery, but do not remove it completely.




Step 1 - checking battery -A-:

- Check by hand that battery clamps -3- and -4- are securely seated. If necessary, tighten nuts -2- and -5- to specified torque (see table of tightening torques for installation ⇒ [page 34](#)).
- Check by hand that battery is securely installed. If necessary, tighten securing bolt -7- on retainer plate -6- to specified torque (see table of tightening torques for installation ⇒ [page 34](#)).


Step 2 - checking second battery -A1-:

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Check by hand that battery clamps -4- and -9- are securely seated. If necessary, tighten nuts -2- and -5- to specified torque (see table of tightening torques for installation ⇒ [page 34](#)).
- Check by hand that battery is securely installed. If necessary, tighten securing bolt -7- on retainer plate -8- to specified torque (see table of tightening torques for installation ⇒ [page 34](#)).

Install in reverse sequence.



3.8 Battery: checking electrolyte level



Note

Batteries must not be opened.

Battery without magic eye ⇒ [page 36](#)

Battery with magic eye ⇒ [page 37](#)

3.8.1 Battery without magic eye

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm
- ◆ Or: torque wrench - V.A.G 1783- , measuring range 2 to 10 Nm
- ◆ Or: torque wrench - VAS 6854- , measuring range 5 to 13 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm

- ◆ Or: torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Nut on accumulator	9


The battery is located under the luggage compartment floor.

Removal steps:

- Lift luggage compartment floor and secure in position.
- Applies to vehicles with adaptive air suspension: Remove nuts -arrows- and move accumulator to side (leave lines -1- and solenoid valve block -2- connected).
- Take out tool kit box.

Procedure:

- Check battery housing for the following:
 - ◆ Battery terminals are not corroded or damaged
 - ◆ Mechanical damage to battery housing and cover, indicated by electrolyte leakage or crystals at the damaged area
- Damaged batteries must be renewed.
- Check electrolyte level of all battery cells using markings on housing.
- If electrolyte level of one or more battery cells is below MIN marking: Renew battery.



Install in reverse sequence. Note tightening torques (see table of tightening torques for installation ➔ [page 37](#)).



Note

- ◆ A bright hand-held light helps to better see the MIN and MAX markings on the housing.
- ◆ If battery is difficult to see: Use a small mirror to check the electrolyte level (shine a bright hand-held light at a right angle onto the battery cells).

3.8.2 Battery with magic eye



WARNING

Risk of explosion if magic eye is colourless or light yellow!

- ◆ Do not attempt to jump-start vehicle.
- ◆ Do not check or charge battery.
- ◆ Renew battery.

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm

- ◆ Or: torque wrench - V.A.G 1783- , measuring range 2 to 10 Nm
- ◆ Or: torque wrench - VAS 6854- , measuring range 5 to 13 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm


Table of tightening torques for installation:

Component/fastener	[Nm]
Nut on accumulator	9

The battery is located under the luggage compartment floor.

Removal steps:


- Lift luggage compartment floor and secure in position.
- Applies to vehicles with adaptive air suspension: Remove nuts -arrows- and move accumulator to side (leave lines -1- and solenoid valve block -2- connected).
- Take out tool kit box.



Protected by copyright. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without prior written permission from Audi AG. Copyright by Audi AG.

Procedure:

- Check battery housing for the following:
 - ◆ Battery terminals are not corroded or damaged
 - ◆ Mechanical damage to battery housing and cover, indicated by electrolyte leakage or crystals at the damaged area
- Damaged batteries must be renewed.
- Before checking electrolyte level: Tap magic eye -arrow- carefully with handle of a screwdriver.
- Read off battery electrolyte level according to colour display. Two different results are possible:



Colour of magic eye:	Measure:
Black or green	Electrolyte level OK: No further measures necessary
Colourless or light yellow	Electrolyte level too low: Battery must be renewed

Install in reverse sequence. Note tightening torques (see table of tightening torques for installation ➔ [page 38](#)).



Note

- ◆ The magic eye is also referred to as an ALI (acid level indicator).
- ◆ The magic eye is only for use in determining the electrolyte level.
- ◆ During battery charging or vehicle operation, air bubbles can form underneath the magic eye which could falsify the colour display. Tap magic eye lightly to release any bubbles.

3.9 Battery: connecting to a stationary battery charging unit for sustained charging

All models except A7 ➔ [page 39](#)

A7 ➔ [page 41](#)

3.9.1 All models except A7



DANGER!

Protected by copyright. Copying for private or commercial purposes is prohibited. All rights reserved. Audi AG does not guarantee the accuracy of the information provided. Audi AG is not responsible for any damage caused by the use of the information provided.

Risk of fatal injury if high-voltage components are damaged.

- ◆ Observe warnings for high-voltage system:
- ◆ Handling high-voltage wires ➔ [page 12](#).
- ◆ For work in the vicinity of high-voltage components ➔ [page 11](#).



WARNING


Risk of injury if battery terminal clamps are connected incorrectly.

- ◆ Connect positive battery terminal clamp first, then connect negative battery terminal clamp.

Special tools and workshop equipment required

- ◆ Battery charger - VAS 5906-

VAS 5906



W00-10798

- ◆ Torque wrench - V.A.G. 1783- , measuring range 2 to 10 Nm
- ◆ Or: torque wrench - V.A.G. 1410- , measuring range 4 to 20 Nm
- ◆ Or: torque wrench - VAS 6854- , measuring range 5 to 13 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm

- ◆ Or: torque wrench - V.A.G. 1331- , measuring range 6 to 50 Nm

Tightening torques table:

Component/fastener	[Nm]
Jump-start connection	9
Cap nut	9


Only applies to vehicles intended for display.

Requirements:


- Ignition switched off.

Removal steps:

- Lift luggage compartment floor and secure in position.
- Take out spare wheel (where applicable).
- Applies to vehicles with air suspension: Detach pressure valve -illustration- from tool kit box (lines remain connected).
- Take out tool kit box.





- Unscrew cap nut -illustration-.
- Screw in jump-start connection - 4F0 972 501- and tighten to specified torque (see table of tightening torques for installation ➔ [page 40](#)).



- Applies to vehicles without towing bracket: Remove rubber grommet -illustration- from spare wheel well and store it in glove box.
- Applies to vehicles with towing bracket: Loosen rubber grommet -illustration- in spare wheel well along with wiring harness and pull it slightly inwards into vehicle.

Procedure for connecting battery charger:

- Disconnect charger clamps from battery charger - VAS 5906- .
- Working from above, thread connector end of cable for charger clamps through hole in spare wheel well and down to underside of vehicle.
- Open battery terminal cover (+).
- First connect charger clamp (+) to positive battery terminal -A-.
- Then connect charger clamp (-) to earth point (-) -B- on body.
- Arrange wiring of battery charger - VAS 5906- neatly in spare wheel well.
- Place vehicle tool kit box in spare wheel well.
- Applies to vehicles with air suspension: Attach pressure valve with lines connected.
- Fit luggage compartment floor cover.
- Under vehicle: Connect cable for charger clamps to battery charger - VAS 5906- .
- Switch on battery charger - VAS 5906- and adjust settings as needed.
- Position battery charger - VAS 5906- under vehicle so that it is hidden from view as well as possible, ensuring that ventilation grille of charger is unobstructed.



Procedure for disconnecting battery charger:

Remove in reverse sequence.

3.9.2 A7




WARNING

Risk of injury if battery terminal clamps are connected incorrectly.

- ◆ *Connect positive battery terminal clamp first, then connect negative battery terminal clamp.*

Special tools and workshop equipment required

◆ Battery charger - VAS 5906-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without permission by Audi AG. Audi AG does not guarantee the accuracy of any liability with respect to the correctness of instructions or the equipment. Copyright by Audi AG.

Only applies to vehicles intended for display.

Requirements:


- Ignition switched off.

Removal steps:


- Remove stopper from wheel housing on right side of vehicle and store it in glove box.

Procedure for connecting battery charger:

- Guide plug of charging cable from above through wheel housing -arrow- and out from underside of vehicle.



- Open cover for jump start connection (+) -3- in direction of -arrow-.
- First connect charger clamp (+) to jump start connection (+) -2-, and ensure that charger clamp does not make contact with bonnet when it is closed.
- Then connect charger clamp (-) to earth point (-) -1- on body, and ensure that charger clamp does not make contact with bonnet when it is closed.
- Arrange wiring of battery charger - VAS 5906- neatly in engine compartment.
- Switch on battery charger - VAS 5906- and adjust settings as needed.
- Position battery charger - VAS 5906- under vehicle so that it is hidden from view as well as possible, ensuring that ventilation grille of charger is unobstructed.



Procedure for disconnecting battery charger:

Remove in reverse sequence.

3.10 Brake fluid: changing



WARNING

Risk of accident if the brake pedal has too much free play.

- ◆ *Make sure that the brakes work properly before the vehicle is driven on the road.*



WARNING

Risk of injury due to caustic brake fluid.

- ◆ *Avoid contact with skin.*



Caution

Risk of damage due to improper handling of brake fluid.

- ◆ *Avoid contact with vehicle paint.*
- ◆ *Avoid contact with liquids containing mineral oils (oil, petrol, cleaning agents).*

Special tools and workshop equipment required

- ◆ Brake filling and bleeding equipment - VAS 5234-



- ◆ Tool set for brake bleeding - VAS 6564-



Table of test values and procedure guidelines:


The value given in the table is for one brake caliper, i.e. if there are two bleeder screws on one caliper, the sum of the quantities

discharged from both bleeder screws must equal the value given in the table.


Sequence of opening bleeder screws:		Quantity of brake fluid to discharge:
Brake calipers		
Front axle on driver's side	1.	0.20 ltr.
Front axle on front passenger's side	2.	0.20 ltr.
Rear axle on driver's side	3.	0.30 ltr.
Rear axle on front passenger's side	4.	0.30 ltr.
Clutch slave cylinder	5.	0.15 ltr.
⇒ Total quantity, automatic gearbox		
		1.00 ltr.
⇒ Total quantity, manual gearbox		
		1.15 ltr.

Step 1 - connecting brake filling and bleeding equipment:

- Unscrew filler cap -1- from brake fluid reservoir.



- Use extraction hose included in brake filling and bleeding equipment - VAS 5234- to extract brake fluid from reservoir (with strainer installed) until fluid is level with bottom edge of strainer. Make sure that no more fluid flows back into reservoir from strainer after extracting fluid.



- Screw adapter -1- onto brake fluid reservoir.
- Connect filling hose -2- included with brake filling and bleeding equipment - VAS 5234- to adapter.
- Set pressure on brake filling and bleeding equipment - VAS 5234- (see operating instructions).


Step 2 - bleeding and filling brake system:

If there are two bleeder screws on each brake caliper, first bleed the inner, then the outer bleeder screw.



- Raise vehicle ➔ [page 15](#) .

Front axle:

- Brake caliper (driver's side): Remove cap(s) -1- from bleeder screw(s).



- Fit bleeder hose -1- attached to collector container onto bleeder screw from inside of rim.
- Open bleeder screw and allow brake fluid to discharge. Refer to table for correct quantity of brake fluid to discharge ➔ [page 43](#) .
- Close bleeder screw.
- If there are two bleeder screws on each brake caliper: Repeat procedure with second bleeder screw.
- Refit cap on bleeder screw(s).
- Repeat procedure on passenger's side.




Rear axle:

- Brake caliper (driver's side): Remove cap(s) -1- from bleeder screw(s).
- Take reversible ratchet and appropriate socket from tool set for brake bleeding - VAS 6564- and fit together.



- Run bleeder hose -1- from inside of rim through reversible ratchet -2- and socket -3- and fit onto bleeder screw.
- Open bleeder screw with ratchet -2- and allow brake fluid to discharge. Refer to table for correct quantity of brake fluid to discharge ➔ [page 43](#) .
- Close bleeder screw.




Protected by copyright. Copying for private or commercial purposes is prohibited without the prior written permission of Audi AG. Audi AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by Audi AG

- If there are two bleeder screws on each brake caliper: Working from outside of rim, apply reversible ratchet -2- and socket -3- and repeat procedure.
- Refit cap on bleeder screw(s) on brake caliper.
- Repeat procedure on passenger's side.

Step 3 - bleeding clutch slave cylinder

Only for vehicles with manual gearbox

- Remove components necessary for access; refer to ➔ Manual gearbox; Rep. gr. 30 ; Clutch mechanism; Bleeding clutch mechanism .
- Fit bleeder hose attached to collector container -1- onto bleeder screw of clutch slave cylinder.
- Open bleeder screw and allow correct amount of brake fluid to flow out (see table of test values and procedure guidelines ➔ [page 43](#)).
- Close bleeder screw and fit cap.



Step 4 - final steps:

- Close filling lever of brake filling and bleeding equipment - VAS 5234- .
- Detach filling hose from adapter.
- Unscrew adapter from brake fluid reservoir.
- Check brake fluid level and adjust if necessary (depending on brake pad wear) ➔ [page 48](#) .
- Screw cap onto brake fluid reservoir.
- Operate clutch pedal several times.
- Check pedal pressure and free travel: No more than $\frac{1}{3}$ of total pedal travel.
- Make sure that the brakes work properly before the vehicle is driven on the road.
- If free travel of brake pedal is greater than specified, or if brake function is impaired: Check brake system for leaks and renew brake fluid again.



Note

- ◆ *The bleeder hose must fit tightly on the bleeder screw to prevent air from entering the brake system.*
- ◆ *In the case of certain wheel combinations, the wheels may have to be removed.*
- ◆ *With the aid of the tool set for brake bleeding - VAS 6564- , the rear brakes or, depending on version, the front and rear brakes can be bled without having to remove the wheels.*
- ◆ *Use genuine Audi brake fluid; see Electronic parts catalogue (ETKA).*
- ◆ *Do not reuse brake fluid.*
- ◆ *Always observe the relevant environmental regulations for disposal of brake fluid.*

3.11 Brake fluid: checking fluid level


Table of test values and procedure guidelines:

Type of service:	Fluid level specification:
Delivery Inspection	Fluid level must be at MAX marking.
Brake fluid change	Fluid level must be between MAX marking and MIN marking according to wear level of brake pads.

Checking the brake system for leaks is a repair measure and should be charged separately.

Procedure:

- Evaluate brake fluid level according to markings -arrows- on brake fluid reservoir.
- Perform the following measures according to the results of the check:



Fluid level:	Evaluation/measure:
Above MAX marking	Extract brake fluid.
Below specified level	Carry out brake system leak test ⇒ Brake system; Rep. gr. 47 ; Hydraulic system; Leak test .



Note

When the vehicle is in use, the fluid level drops due to wear and automatic adjustment of the brake pads.

3.12 Brake system: checking condition of brake hoses, and checking that caps are fitted on bleeder screws

Requirements:

- Brake hoses must not touch any components when steering is on full lock.
- Brake hoses must not be twisted.

Procedure:

- Check that all brake hoses are secured properly; when doing so, ensure that the conditions listed are met:
- Check all brake hoses for abrasion, porosity, blistering and cracking.
- Check that brake connections are seated correctly, and check for corrosion and leaks.

- If faults are found on brake hoses: Repair/renew relevant component.
- Check that caps are fitted and secured on bleeder screws of all brake calipers.
- Renew any missing caps.

3.13 Brake pads: checking thickness

Special tools and workshop equipment required

- ◆ Test pin - T40139- : Use the side with the thin probe (brake symbol) to measure brake pad thickness.




Table of test values and procedure guidelines:

Axle	Brake pad wear limit including backplate and damper plate [mm]
Front axle:	9
Rear axle:	8

Check only the thickness of the outer brake pads.

Procedure:


- Before you begin: Push sliding ring towards tip of test pin as far as it will go.
- Bring tip of test pin into contact with brake disc.
- Slide test pin towards brake pad until test pin makes contact with backplate of brake pad.

- Remove test pin and read off brake pad wear value -a- from scale on tool.
- Repeat procedure for all wheels.
- If brake pad thickness has reached wear limit (see table of test values and procedure guidelines ➔ [page 49](#)): Renew brake pads ➔ Brake system; Rep. gr. 46; Removing and installing brake pads.



Note

- ◆ When removing the test gauge, take care not to move the sliding ring. This would give an incorrect measurement.
- ◆ Note where the test gauge makes contact on the rear of the brake pad and include the thickness of the damper plate in the calculation if necessary.
- ◆ In the case of certain wheel combinations, the wheels must be removed.



3.14 Tyres: checking condition and wear pattern, and checking and recording tread depth

Special tools and workshop equipment required

- ◆ Test pin - T40139- : Use the side with the thick probe and shoulder (scale marked with tyre symbol) to measure tread depth.




Table of test values and procedure guidelines:

Country-specific regulations for minimum tread depth apply; for countries not listed, evaluate values according to the country's specifications.

Country	Minimum tread depth [mm]
EU countries	1.6 ¹⁾
Brazil	1.6
China	1.6
India	1.6
Japan	1.6
Norway	1.6 ¹⁾
Russia	1.6
Switzerland	1.6
Turkey	1.6

Country	Minimum tread depth [mm]
Ukraine	1.6 ¹⁾
USA	1.6

1) Larger values for winter tyres where these are mandatory

Performing wheel alignment is a repair measure and should be charged separately.

Step 1 - checking condition:

- Check for and remove any foreign bodies in tyre tread.
- Check all tyres for following types of damages:

- ◆ Cuts, cracks, tears
- ◆ Scuffing or flattened areas on tyre tread
- ◆ Porous sidewalls
- ◆ Blisters on sidewalls
- If damage is found: Renew tyres.

Step 2 - checking tyre wear pattern:

- Check tyre wear pattern of front wheels; check for the following:
- ◆ Feathering on tread indicating possible incorrect toe setting
- ◆ One-sided tread wear indicating possible incorrect camber
- If the above types of wear are found: Check wheel alignment to determine the cause.

Step 3 - checking tread depth:

- Measure tread depth on all tyres (including spare tyre) at several points using test pin - T40139- . Uneven tread depth indicates damage.
- Record average measurement for each tyre in Maintenance table.
- If minimum tread depth has been reached (as specified for your country; see table of test values and procedure guidelines ⇒ [page 50](#)): Renew tyre.



Note

Vehicles with four-wheel drive must be fitted with tyres with the same tread pattern. Otherwise the centre differential may be damaged.

3.15 Tyres: checking tyre pressures and adjusting if necessary



Note

The tyre valves must be sealed with valve caps. Otherwise, dirt could enter the valve, which will then become blocked and will no longer seal properly.

Front and rear axles ➔ [page 52](#)

Spare wheel and temporary spare wheel ➔ [page 52](#)

3.15.1 Front and rear axle

The tyre pressure specifications are listed on the sticker on the inside of the driver's door.

Tyre sizes not listed: See Wheel/tyre guide for tyre pressure specification ➔ Wheel/Tyre Guide; Rep. gr. 44 ; Wheels, tyres, vehicle geometry; Tyre pressures .


Procedure:

- Check tyre pressure of all tyres.
- If necessary, adjust to correct tyre pressures.



Note

The tyre pressures listed only apply to cold tyres. When the tyres are warm, the actual pressures will be higher, but must not be reduced.



3.15.2 Spare wheel and temporary spare wheel

The following parameters apply to the tyre pressure specifications:

- Spare wheel with standard-size tyre: Inflate to maximum tyre pressure indicated on tyre pressure sticker.
- Temporary spare wheel: The correct tyre pressure is indicated on the sidewall.

Procedure:

- Check tyre pressure of spare wheel/temporary spare wheel.
- If necessary, adjust to correct tyre pressures.



Note

Depending on equipment version, there may only be a tyre repair kit supplied; see Maintenance table.

3.16 Tyre Pressure Loss Indicator: storing changed tyre pressures



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ Observe warnings for high-voltage system:
- ◆ For work that must be performed with the ignition switched on ➔ [page 13](#) .

The Tyre Pressure Loss Indicator must be initialised after every time the tyre pressures are changed or the tyres are renewed.

Requirements:

- The inflation pressures of all tyres must be adjusted to the correct values before the pressures are stored.

Procedure:


- Switch on ignition and activate MMI.
- Press function selector button **CAR**.
- Under »Systems«, navigate through following menu structure:
 - ◆ Servicing & checks
 - ◆ Tyre pressure monitoring
 - ◆ Store tyre pressures
- Use MMI rotary pushbutton to select option to store tyre pressures.

3.17 Tyre repair kit: checking that set is complete, and checking and recording expiry date

The tyre repair kit is located under the luggage compartment floor.

Procedure:

- Check that the following components of the tyre repair kit are present:
 - ◆ Compressor
 - ◆ Tyre filler bottle incl. filler hose
- Take out the bottle and check the expiry date (printed on bottle -arrow-).
- Record expiry date in Maintenance table.
- If expiry date has been exceeded or if bottle has already been used: **Renew tyre filler bottle.**



3.18 Tool kit: checking that all components necessary in the event of a breakdown are present

The tool kit is located under the luggage compartment floor.

The vehicle jack is located under the luggage compartment floor.

Procedure:

- Check that jack (including crank handle) is present.
- Check that following components of tool kit are present:
 - ◆ Wheel bolt spanner
 - ◆ Adapter for anti-theft wheel bolts
 - ◆ Puller
 - ◆ Clip

- ◆ Towing hook
- Renew any missing components.

3.19 Wheel bolts: tightening to specified torque

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1332- , measuring range 40 to 200 Nm
- ◆ Or: torque wrench - V.A.G 1576- , measuring range 80 to 400 Nm

Table of test values and procedure guidelines:

Fastener	Tightening torque [Nm]
Wheel bolts	120

The adapter for loosening and tightening anti-theft wheel bolts is included in the vehicle tool kit.

Procedure:

- Tighten wheel bolts in a diagonal sequence to specified torque (see table of test values and procedure guidelines [⇒ page 54](#)).
- If adapter for anti-theft wheel bolts was used from tool kit: Put adapter back in tool kit.

Protected by copyright. Copying for private or commercial purposes is prohibited without the written consent of Audi AG. Audi AG does not guarantee or warrant any liability with respect to the correctness of information in this document prepared by Audi AG.

3.20 Suspension struts on front and rear axle: removing locking elements




Note

- ◆ *These vehicles are identified by a coloured tag fixed to the mirror -arrow-.*
- ◆ *It is not necessary to remove the wheels to perform this operation.*

Suspension struts on front axle [⇒ page 54](#)

Suspension struts on rear axle [⇒ page 55](#)

Pressing in bump stop [⇒ page 56](#)




3.20.1 Suspension struts on front axle

Requirements:

- Vehicle suspension extended

Procedure:


- Push all locking elements -A- off piston rod.
- When all locking elements have been removed from vehicle:
Remove tag on interior mirror.



- After road test: Check that all bump stops are firmly seated in shock absorber mountings.
- If necessary, press any loose bump stops into shock absorber mountings ➔ [page 56](#).

 **Note**

The bump stops of the suspension struts are pressed into the shock absorber mountings due to the compression movements during the road test.




3.20.2 Suspension struts on rear axle

Requirements:

- Vehicle suspension extended

Procedure:

- Push all locking elements -1- off piston rod.
- When all locking elements have been removed from vehicle:
Remove tag on interior mirror.



Printed by copyright. Copying for private or commercial purposes is prohibited. All rights reserved. Audi AG, Audi AG does not guarantee the accuracy of the information in this document. Copyright © 2015 Audi AG.


- After road test: Check that all bump stops are firmly seated in shock absorber mountings.
- If necessary, press any loose bump stops into shock absorber mountings ➔ [page 56](#).



Note

The bump stops of the suspension struts are pressed into the shock absorber mountings due to the compression movements during the road test.

Protected by Copyright. Copying for private or commercial purposes in part or in whole is permitted without restriction by Audi AG. Audi AG does not accept any responsibility with respect to the correctness of information in this document. Copyright © Audi AG




3.20.3 Pressing in bump stop

Special tools and workshop equipment required

- ◆ Soap-based lubricant, e.g. tyre assembly paste

Procedure:

- Remove coarse dirt from top edge of loose bump stop and coat with tyre assembly paste.
- Press loose bump stop firmly into shock absorber mounting by hand.



3.21 Components of front and rear axles: checking play, secure attachment and protective boots

The following applies to all components shown below:

- There must be no noticeable or visual play.
- As a rule you can identify damage to the boots/drive shaft boots by emerging grease.
- Check that retaining rings and spring-type clips are seated correctly.


Front axle ➤ [page 57](#)

Rear axle ➤ [page 59](#)


3.21.1 Front axle

Track control links, guide links and coupling rod:

- Check relative movement between wheel bearing housing and track control link/guide link.




- Track control link and guide link: Check boots -arrows- of track control link and guide link joints all around for damage and make sure they are seated correctly.
- Check swivel joints for play.



- Check all bonded rubber bushes of track control links and guide links -arrows- for play.
- Check play at coupling rod -1-.

Track rod ball joint:



Protected by copyright. Copying for private or commercial purposes is permitted in whole or in part, provided the source is acknowledged. Audi AG is not responsible for the correctness of the information in this document. Copyright by Audi AG.

- Check boot -2- for track rod ball joint all around for damage and make sure it is seated correctly.
- Check play at track rod ball joint.

Upper links:





- Upper links -2-: Check bushes of swivel joints all around for damage and make sure they are seated correctly.
- Check swivel joints for play.
- Check bonded rubber bushes -3- and -4- of swivel joints (top) for play.

Anti-roll bar:

- Check anti-roll bar bush -3- for damage.

Drive shaft and steering rack:


- With steering turned: Check drive shaft boots -arrows- all around for damage and make sure they are seated correctly.
- Check boot -arrow- of steering rack all around for damage and correct seating.
- Repeat checks for components on opposite side of vehicle.
- If faults are found on any of the above components: Renew relevant component.



3.21.2 Rear axle


Lower and upper transverse links:

- Check relative movement between wheel bearing housing and both transverse links.
- Check all bonded rubber bushes -arrows- of lower transverse link for play.




- Check all bonded rubber bushes of upper transverse link -3- for play.

Track rod:




- Check play at bonded rubber bushes of track rod -4-.

Coupling rod and anti-roll bar:



- Check play at coupling rod -4-.




Protected by copyright. Copying for private or commercial purposes, in part or in full, is prohibited without the written permission of Audi AG. Audi AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by Audi AG.


- Check anti-roll bar bush -1- for damage.

Drive shaft:

Only applies to vehicles with four-wheel drive.



- Check drive shaft boots -1- all around for damage and make sure they are seated correctly.
- Repeat checks for components on opposite side of vehicle.
- If faults are found on any of the above components: Renew relevant component.



3.22 Engine, gearbox, final drive and steering: checking for leaks and damage



DANGER!

Risk of fatal injury if high-voltage components are damaged.

- ♦ **Observe warnings for high-voltage system:**
- ♦ **For work in the vicinity of high-voltage components**
⇒ page 11 .

Applies to vehicles up to and including model year 2014: For inspection every 60,000 km (38,000 miles)/4 years, remove noise insulation.

Applies to vehicles from model year 2015 onwards: Remove noise insulation for every inspection.

Removal steps:

- If necessary, remove noise insulation ⇒ [page 21](#) .

Procedure:

- Check engine and engine ancillaries from below for leaks and damage.
- Check radiator and cooling circuit for leaks and damage.
- Check refrigerant circuit for damage (check air conditioner compressor, condenser and refrigerant lines including connections).
- Check gearbox, final drive and steering for leaks and damage.
- If faults are found: repair or renew relevant component.

3.23 Underbody: checking trim, wheel housing liners, side members and pipes/wiring for damage, and checking that they are properly secured

Procedure:

- Check all underbody trim panels and wheel housing liners for tears and cracks.
- Use your hands to check that all underbody trim panels and wheel housing liners are secured correctly and check for missing fasteners.
- Inspect side members for deformations.
- Check visible area of pipes/wiring and connections for damage and ensure they are secured correctly.
- If faults are found: Renew missing fastener or damaged component.

3.24 Roof insert: checking operation



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ⇒ [page 13](#).*

Only applies to equipment version with sliding/tilting sunroof.

Cleaning and lubricating the roof insert is a repair measure and should be charged separately.

Procedure:

- Open and close roof system completely and check for unusual noises and stiffness/sticking.
- If there is unusual noise or stiffness/sticking: Clean and lubricate roof insert ⇒ [page 61](#).

3.25 Roof insert - sliding/tilting sunroof: cleaning and lubricating



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ⇒ [page 13](#).*

Special tools and workshop equipment required

- ◆ Lubricating paste - G 060 751 A2-
- ◆ Krytox lubricating paste - G 052 141 A2-
- ◆ Cleaning solution - D 009 401 04-



- ◆ Industrial vacuum cleaner, e.g. wet/dry vacuum cleaner - VAS 5128-
- ◆ Commercially available paintbrush: approx. 15 mm wide and bent by approx. 40°
- ◆ Fine-pored sponge (e.g. a piece of household sponge without a scouring surface)

Cleaning and lubricating the roof insert is a repair measure and should be charged separately.

Protect vehicle interior from becoming dirty.

Step 1 - cleaning and lubricating glass panel seal:

- Tilt open glass panel at rear.
- Remove all accessible grease and dirt residue from glass panel seal using cleaning solution - D 009 401 04- and a lint-free cloth.
- Use a fine-pored sponge -1- to lubricate sides and rear of glass panel seal -arrows- with Krytox lubricating paste - G 052 141 A2- . Make sure that no coarse residue remains visible after applying lubricant.
- Open glass panel completely.
- Using cleaning solution - D 009 401 04- and a lint-free cloth, remove any grease or dirt residue from front of glass panel seal in area that has not been lubricated yet.
- Use a fine-pored sponge -1- to lubricate glass panel seal at front -arrow- with Krytox lubricating paste - G 052 141 A2- . Make sure that no coarse residue remains visible after applying lubricant.




Step 2 - cleaning and lubricating guide rail:


Glass panel opened completely.

- First use an industrial vacuum cleaner to remove any loose residue from guide rails.
- Remove grease and dirt from guide rails with a lint-free cloth.


- Use a paintbrush to lubricate inside of guide rail -arrow- with lubricating paste - G 060 751 A2- .



- Use a paintbrush to lubricate outside of guide rail -arrow- with lubricating paste - G 060 751 A2- .



- Use a paintbrush to lubricate side guide rail of sliding headliner -arrow- with lubricating paste - G 060 751 A2- .
- Remove surplus lubricant on guide rails with a lint-free cloth.
- Repeat procedure on opposite side of vehicle.
- Open and close roof system completely and check again for surplus lubricant.



Protected by copyright. Copying for private or commercial purposes, in part or in full, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee the correctness of information in this document. Copying is prohibited.

3.26 Roof insert - panorama sunroof: cleaning and lubricating



WARNING


Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ➔ page 13.*

Special tools and workshop equipment required

- ◆ Lubricating paste - G 060 751 A2-
- ◆ Krytox lubricating paste - G 052 141 A2-
- ◆ Cleaning solution - D 009 401 04-
- ◆ Grease stone - VAS 6764-


VAS 6764



W00-11393

- ◆ Hand-cartridge gun - V.A.G 1628-

V.A.G 1628



W00-0536

- ◆ Industrial vacuum cleaner, e.g. wet/dry vacuum cleaner - VAS 5128-
- ◆ Measuring cup
- ◆ Commercially available paintbrush: approx. 15 mm wide and bent by approx. 40° using workshop equipment
- ◆ Fine-pored sponge (e.g. a piece of household sponge without a scouring surface)


Protected by copyright. Copying for private or commercial purposes, in particular without permission, is prohibited by AUDI AG. AUDI AG does not guarantee the accuracy of any liability.

Cleaning and lubricating the roof insert is a repair measure and should be charged separately.

Protect vehicle interior from becoming dirty.


Step 1 - cleaning and lubricating guide rails:

- Open sunroof sun blind completely.
- Open glass panel completely.
- First use an industrial vacuum cleaner to remove any loose residue from guide rail.
- Insert grease stone - VAS 6764- in rear section of guide rail -1- and turn 90° into contour of rail -2-.
- Then pull tool into centre of guide rail opening -3-, turn through 90° again -4- and remove -5-.
- Clean front section of guide rail as described in previous step. To do so, insert grease stone in front section of guide rail (near wind deflector) and move it to centre of guide rail.
- Repeat cleaning procedure several times as required.
- Remove grease and dirt deposits from guide rail with a lint-free cloth.
- Repeat procedure on opposite side of vehicle.




- Screw grease stone - VAS 6764- -1- onto thread of lubricant cartridge -G 060 751 A2- -2- and insert into hand-cartridge gun - V.A.G 1628- -3-.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG




- Insert grease stone attached to hand-cartridge gun at front end of guide rail -1- and turn 90° into contour of rails -2-.
- Pull hand-cartridge gun evenly towards rear -3-, operating lever continuously to apply lubricating paste - G 060 751 A2- to guide rail.
- Turn hand-cartridge gun through 90° -4- and remove in vicinity of open glass panel -5-.
- Repeat lubrication procedure on opposite side of vehicle.



Step 2 - cleaning and lubricating slotted guide for glass panel:


Glass panel opened completely.

- Remove grease and dirt from slotted guide for glass panel with a lint-free cloth.
- Open and close sunroof and open glass panel again completely. Opening and closing the sunroof distributes the lubricant along the guide rails. Any deposits of excess lubricant can be used to grease the slotted guide.
- Use a paintbrush to lubricate slotted guide for glass panel -arrow- with lubricating paste - G 060 751 A2- .
- Remove excess lubricant from slotted guide and guide rail with a lint-free cloth.
- Repeat procedure on opposite side of vehicle.



Step 3 - cleaning and lubricating locking hook for sunroof mechanism:

- Tilt open glass panel.
- Working from vehicle interior, remove grease and dirt from locking hook for sunroof mechanism with a lint-free cloth.
- Use a paintbrush to lubricate locking hook -arrow- with lubricating paste - G 060 751 A2- .
- Remove surplus lubricant from locking hook with a lint-free cloth.
- Repeat procedure on opposite side of vehicle.
- Open and close roof system completely and check again for surplus lubricant at all lubricating locations.



Step 4 - cleaning glass panel:


- Open glass panel completely.

- Remove grease and dirt from front and side edges of glass panel -arrows- using cleaning solution - D 009 401 04- and a lint-free cloth.

Step 5 - cleaning and lubricating roof frame seal:

Glass panel opened completely.


- Remove grease and dirt from seal for roof frame using cleaning solution - D 009 401 04- and a lint-free cloth.




- Use a fine-pored sponge to lubricate roof frame seal -arrows- with Krytox lubricating paste - G 052 141 A2- . Make sure that no coarse residue remains visible.

Step 6 - cleaning wind deflector:

Glass panel opened completely.




- Clean screen and frame of wind deflector -1- using a sponge and soap solution.
- Use an industrial vacuum cleaner to remove any loose residue from wind deflector slot -arrows-.



Step 7 - checking water drains for dirt:

Glass panel opened completely.

- Use a measuring cup -1- to pour water into guide rail close to open glass panel -arrow-. Work carefully to ensure that the water does not overflow into the vehicle interior. Make sure that water is distributed in both directions so that both water drains can be checked.
- At underside of vehicle, check that water flows out in the area of both the front and rear wheel housings.
- Repeat procedure on opposite side of vehicle.
- If water does not flow out of the appropriate drainage points, clean water drain ⇒ General body repairs, exterior; Rep. gr. 60 ; Water drain hoses; Cleaning water drain hoses .



3.27 Rear spoiler hinges: lubricating

Special tools and workshop equipment required


- ◆ Lubricant - G 052 172 A1-

Requirements:

- The vehicle must be at least at room temperature.

Procedure:

- Switch on ignition and extend rear spoiler.
- First clean all lubricating points with a lint-free cloth.
- Apply lubricant - G 052 172 A1- to points marked on all rear spoiler hinge joints -arrows-.
- Extend and retract rear spoiler at least five times so that lubricant is able to penetrate.
- Remove surplus lubricant with cloth.
- Repeat procedure on opposite side.
- Retract rear spoiler.



3.28 Bonnet arrester hook: lubricating

Special tools and workshop equipment required

- ◆ Universal spray oil - G 000 115 A2-


Requirements:

- The vehicle must be at least at room temperature.

Procedure:

- First clean all lubricating points with a lint-free cloth.

- Lubricate arrester hook with universal spray oil - G 000 115 A2- at points marked -arrows-.
- Operate moving parts several times so that the lubricant is able to penetrate.
- Remove surplus lubricant with cloth.



3.29 Windscreen/rear window washer system: checking spray pattern and adjusting if necessary

Checking windscreen spray pattern: triple washer jets
⇒ [page 69](#)

Checking windscreen spray pattern: hybrid jets ⇒ [page 70](#)

Checking spray pattern on rear window ⇒ [page 70](#)

Setting windscreen spray pattern, triple washer jets ⇒ [page 70](#)

Setting windscreen spray pattern: hybrid jets ⇒ [page 71](#)

Adjusting rear window washer jets ⇒ [page 71](#)

3.29.1 Checking windscreen spray pattern: triple washer jets


The spray pattern must meet the following specifications:

- Evenly distributed, symmetrical spray pattern
- Uniform, precise jets of water
- Jet unit (passenger's side): Water from all washer jets makes contact within upper third of wiper area -illustration-
- Jet unit (driver's side): Spray pattern symmetrically opposite that of jet unit on passenger's side

Procedure:

- Operate windscreen washer system and check spray pattern.

- If spray pattern is not as specified, adjust windscreen washer jets ⇒ [page 70](#)



Protection of personal data: This document contains information that may be subject to copyright. Any reproduction or distribution of this document is prohibited without the written permission of Audi AG. Audi AG does not accept any liability for the correctness of the information in this document. Copyright © Audi AG.


3.29.2 Checking windscreen spray pattern: hybrid jets

The spray pattern must meet the following specifications:

- Evenly distributed, symmetrical spray pattern
- Uniform, precise jets of water
- Jet unit (passenger's side): Upper concentrated jet should make contact near upper edge of wiper area -1-.
- Jet unit (driver's side): Upper concentrated jet should make contact -2- at same level as jet unit (passenger's side).

Procedure:

- Operate windscreen washer system and check spray pattern.
- If spray pattern is not as specified, adjust windscreen washer jets ➔ [page 71](#) .




3.29.3 Checking spray pattern on rear window

The spray pattern must meet the following specifications:

- Water from both spray jets makes contact just above wiper blade
- Uniform, precise jets of water
- Water from inner spray jet makes contact within approx. first quarter of wiper blade length -illustration-
- Water from outer spray jet makes contact approx. at or just beyond centre of wiper blade length -illustration- (third quarter)

Procedure:

- Operate rear window washer system and check spray pattern.
- If spray pattern is not as specified, adjust rear window washer jets. ➔ [page 71](#)



3.29.4 Setting windscreen spray pattern: triple washer jets

Special tools and workshop equipment required

- ◆ Commercially available adjusting tool (e.g. adjusting tool - T10127-) or suitable needle

Procedure:

- Use adjusting tool to align washer jets as required according to specification.
- If the spray pattern still does not correspond to the specification, clean washer jets ➔ Vehicle electrics; Rep. gr. 92 ; Windscreen wash/wipe system; Adjusting and cleaning washer jets .

Procedure:

- Operate headlight washer system and check function.
- If water jet does not contact headlight: Renew relevant washer jets ⇒ Electrical system; Rep. gr. 92 ; Headlight washer system; Removing and installing washer jets .



Note

The headlight washer jets are set by the manufacturer and therefore cannot be adjusted.

3.32 Headlights: checking for correct adjustment

Special tools and workshop equipment required

- ◆ Headlight adjustment unit - VAS 5209B-



- ◆ Or: headlight adjustment unit - VAS 621 001-

Performed as part of an inspection, this check is merely an abbreviated form of the headlight adjustment check required, for example, after a repair, and does not take the place of a full headlight adjustment check.

Do not adjust the vehicle load or the tyre pressures for this procedure.


Do not adjust the headlights to their basic setting using the vehicle diagnostic tester.

Checking and adjusting the headlights according to the instructions in the Workshop Manual is a repair measure and must be charged separately.


Procedure:

- For vehicles with manually adjustable headlight range control: Use manual adjuster to set to basic setting.
- Activate dipped headlights.

- Align headlight adjustment unit parallel to vehicle and position it centrally in front of headlight at a distance of 30 to 70 cm -distance a-; deviation from centre of light emission surface must not exceed 3 cm -distance b-.



- Adjust dip setting of headlight adjustment unit so that beam of headlight falls on test screen according to following parameter: Horizontal light-dark border should coincide with setting line -1-.
- Read off dip setting of headlight adjuster.
- Repeat procedure on opposite side.
- Compare dip setting on left and right sides.
- If they deviate 2.0% or more from one another: Check and adjust headlight setting according to procedure specified in Workshop Manual ➔ Electrical system; Rep. gr. 94 ; Headlights; Adjusting headlights .



3.33 Headlights and reversing lights, side lights, number plate lights, turn signals, hazard warning lights: checking operation



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ Observe warnings for high-voltage system:
- ◆ For work that must be performed with the ignition switched on ➔ [page 13](#) .

Check the lights/signals listed below from the outside to ensure they function properly.

Procedure:

- Activate side lights and check that the following exterior lights function properly:
 - ◆ Side lights (front)
 - ◆ Side lights (rear)
 - ◆ If applicable: additional tail light under open rear lid
- Switch on ignition.
- Check operation of daytime running lights (front).
- Operate right turn signal, left turn signal and hazard warning lights, and check that corresponding turn signal lamps at front, rear and side function properly.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without the written permission of AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Activate dipped headlights and check that the following exterior lights function properly:
 - ◆ Dipped headlights
 - ◆ Taillights
 - ◆ Number plate lights
- Use appropriate switch to activate fog lights and check that they function properly.
- Check that main beam headlights function properly.
- Operate brakes and check function of all brake lights.
- Engage reverse gear and check that all reversing lights function properly. This model is fitted with two reversing lights.
- Use appropriate switch to activate rear fog lights and check that they function properly. This model is fitted with two rear fog lights.
- Renew any defective bulbs.



Note

It is possible to deactivate the daytime running lights intentionally via the appropriate MMI setup menu.

3.34 Luggage compartment lighting: checking operation

A6 Avant ➔ [page 74](#)


A6 Saloon ➔ [page 75](#)

A7 ➔ [page 75](#)

3.34.1 A6 Avant

Procedure:


- Check that luggage compartment lights shown -arrows- function properly.



3.34.2 A6 Saloon

Procedure:


- Check that luggage compartment light shown -arrows- functions properly.



3.34.3 A7

Procedure:

- Check that luggage compartment lights shown -arrows- function properly.



3.35 Glove box light, interior lighting and reading light: checking operation



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ Observe warnings for high-voltage system:
- ◆ For work that must be performed with the ignition switched on ⇒ [page 13](#).

Procedure:

- Open glove box and check that glove box light functions properly.
- Use the appropriate switches to activate the following interior lights and check that the lights function properly:
 - ◆ Interior lights in headliner at front
 - ◆ Interior lights in headliner at rear



Note

Checking the ambient lighting is NOT part of the inspection.

3.36 Horn: checking operation



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ➔ [page 13](#).*

Procedure:

- Switch on ignition.
- Operate horn and check proper function of treble horn and bass horn.



Note

Perform this check outdoors, e.g. when driving the vehicle to the workshop or during a road test.

3.37 Front passenger's airbag: checking key switch on / off and setting to "on"



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!


- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ➔ [page 13](#).*

Protected by copyright. Copying for private and commercial purposes, in part or in whole, is not permitted. Please inform us if you find any errors or omissions. We will be happy to correct any errors. Subject to the conditions of a trademark in this document. Copyright by Audi AG.

Switch for "Airbag ON/OFF" is located in glove box -arrow-.

Procedure:

- Turn switch to "AIRBAG OFF" position.
- Switch ignition on and wait for vehicle to complete initial system check.
- Check that "PASSENGER AIRBAG OFF" display lights up in instrument cluster.
- Switch off ignition.
- Turn switch to "AIRBAG ON" position.
- Switch ignition on and wait for vehicle to complete initial system check.
- Check that "PASSENGER AIRBAG OFF" disappears.
- Switch off ignition.



The amount of time needed for the vehicle system check varies depending on the model and equipment.

3.38 Seat belts: checking that retaining rivets are fitted, and checking locking action of automatic belt retractor

Procedure:

For all seat belts installed:

- Check that retaining rivets/clips are fitted.
- Check locking action of automatic belt retractors when belt is unrolled abruptly.



If the seat belt is securing an object (e.g. child seat), do not release the seat belt. Only check the locking action when the belt is buckled; it is not necessary to check the retaining rivet/clip in this case.

3.39 Instrument cluster: checking warning lamps

Reading out the event memory is a repair measure and should be charged separately.

Procedure:

- Start engine and wait for vehicle to complete initial system check.
- Check whether warning lamps light up in instrument cluster.
- Switch off engine.
- If relevant warning lamps light up: Read out event memory
⇒ [page 29](#) .



Note

The amount of time needed for the vehicle system check varies depending on the model and equipment.

3.40 Warning triangle: checking availability

Procedure:

- Check that warning triangle(s) is/are present.

3.41 First-aid kit: checking and recording expiry date

The first-aid kit is located in the centre armrest of the rear seat bench.

Procedure:

- Take out first-aid kit and check expiry date printed on kit.
- Record expiry date in Maintenance table.
- If expiry date has passed: Renew first-aid kit.

3.42 Vehicle keys: checking operation and recording number of keys given to customer

Procedure:

- Open key ring to check each key individually.
- Start engine with each key individually.
- Record number of keys which have been matched and handed over in Maintenance table.
- If a vehicle key has not been matched: Re-match all keys to vehicle using Guided Function of vehicle diagnostic tester via online tool GeKo.
- If there is reason to suspect improper use (e.g. missing key): See current notices from AUDI AG under "Technical information ► Anti-theft protection" on ServiceNet.



Note

- ◆ *Only the key being checked may be inside the vehicle. Place all other keys out of transmission range.*
- ◆ *If the key has not been matched, the engine will turn off after a few seconds. In addition, the warning lamp for the immobiliser or the display "SAFE" will appear in the instrument cluster, depending on the vehicle equipment.*

3.43 Engine oil: draining



Note

- ◆ *Oil should always be changed when engine is warm.*
- ◆ *Always observe the relevant environmental regulations for disposal.*
- ◆ *Keep components clean.*

8-cyl. petrol engine 4.0 ltr. TFSI ➔ [page 79](#)

4-cyl. diesel engine 2.0 ltr. TDI ➔ [page 80](#)

3.43.1 8-cyl. petrol engine 4.0 ltr. TFSI

Special tools and workshop equipment required

- ◆ Used oil collection and extraction unit - V.A.S 6622 A-



- ◆ Torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Oil drain plug on sump	20
Oil drain plug on oil filter cover	4


Removal steps:

- Remove noise insulation ➔ [page 21](#)

Procedure:

- Place oil drip tray under engine sump.

- Unscrew oil drain plugs -arrows- of sump and in oil filter cover -1-.
- Drain engine oil from oil filter housing and sump.
- Renew seals of both oil drain plugs.
- Re-install both oil drain plugs and tighten to specified torque (see table of tightening torques for installation ➔ [page 79](#)).



3.43.2 4-cyl. diesel engine 2.0 ltr. TDI

Special tools and workshop equipment required

- ◆ Used oil collection and extraction unit - V.A.S 6622 A-



- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Oil drain plug on sump	30

Removal steps:

- Remove noise insulation ➔ [page 21](#) .


Procedure:

- Place oil drip tray under engine sump.

- Unscrew oil drain plug of sump -arrow-.
- Drain engine oil from sump.
- Renew seal for oil drain plug.
- Screw oil drain plug into sump and tighten to specified torque (see table of tightening torques for installation ➔ [page 80](#)).

Continue installation in reverse sequence.

Protected by copyright. Copying for private or commercial purposes is permitted, in part or in whole, is prohibited by Audi AG. All rights reserved. Audi AG is not responsible for errors or omissions with respect to the correctness of information in this document. Copyright by Audi AG.



3.44 Engine oil: extracting

Special tools and workshop equipment required

- ◆ Used oil collection and extraction unit - V.A.S 6622 A-



Procedure:

- Pull oil dipstick/sealing plug out of guide tube.
- Insert extraction probe of oil extraction unit into guide tube. Use flexible extraction probe with largest possible diameter and insert without using any significant force. Otherwise the tip can become diverted on the bottom of the sump and a large amount of used oil will remain in the engine.
- Extract engine oil completely. Observe operating instructions for extraction unit.
- Finally, install oil dipstick/sealing plug.



Note

- ◆ *Oil should always be changed when engine is warm.*
- ◆ *Always observe the relevant environmental regulations for disposal.*
- ◆ *Keep components clean.*

3.45 Engine oil: renewing oil filter

4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/2.0 ltr. TFSI hybrid
⇒ [page 82](#)

6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI ⇒ [page 83](#)

6-cyl. petrol engine 3.0 ltr. TFSI ⇒ [page 84](#)

8-cyl. petrol engine 4.0 ltr. TFSI ⇒ [page 85](#)

4-cyl. diesel engine 2.0 ltr. TDI (version 1) ⇒ [page 86](#)

4-cyl. diesel engine 2.0 ltr. TDI (version 2) ⇒ [page 87](#)

6-cyl. diesel engine 3.0 ltr. TDI ⇒ [page 88](#)

3.45.1 4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/ 2.0 ltr. TFSI hybrid




DANGER!

Risk of fatal injury if high-voltage components are damaged.

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work in the vicinity of high-voltage components*
⇒ [page 11](#) .

Special tools and workshop equipment required

- ◆ Oil filter tool - 3417-



- ◆ Hazet strap wrench - 2171-1-
- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Oil filter cartridge	22


Removal steps:

- Remove engine cover panel ⇒ [page 17](#) .

Procedure:

- Use Hazet strap wrench - 2171-1- or oil filter tool - 3417- to slacken oil filter cartridge -arrow- and then remove it.
- Clean sealing surface for oil filter at engine.
- Lubricate rubber seal on new oil filter cartridge with engine oil.
- Fit new oil filter cartridge on engine and tighten to specified torque (see table of tightening torques for installation ⇒ [page 82](#)).

Continue installation in reverse sequence.



3.45.2 6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm

Table of tightening torques for installation:


Component/fastener	[Nm]
Sealing cap	25

Removal steps:

- Remove engine cover panel ⇒ [page 17](#) .

Procedure:


- Loosen sealing cap -arrow- of oil filter using socket (36 mm) . This causes a valve to open.
- Wait a few minutes to allow engine oil to drain from filter housing into crankcase.
- Completely remove sealing cap -arrow- of oil filter. Make sure that no engine oil drips onto engine.



Produced by copyright. Copying for private or non-commercial purposes is permitted in whole or part, provided sources are indicated by Audi AG. Audi AG does not accept any liability for damages resulting from the use of this document. Copyright by Audi AG.


- Pull oil filter element and seal -2- out of sealing cap -1-.
- Clean sealing surface -B- of sealing cap -1-.
- Lightly lubricate new seal -2- with engine oil and insert into sealing cap. Note position of service tab -A- on seal. Flat side of seal profile must face outwards.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without the express written permission of Audi AG. All rights reserved. Audi AG does not accept any liability with regard to the correctness of information in this document. Copyright Audi AG.



- Remove O-ring -2- on oil filter housing -1-.
- Lightly lubricate new O-ring -2- with engine oil and insert into groove -arrow-.
- Fit new oil filter element in sealing cap.
- Screw sealing cap into oil filter housing and tighten it to specified torque using socket (36 mm) (see table of tightening torques for installation ➔ [page 83](#)).

Continue installation in reverse sequence.



3.45.3 6-cyl. petrol engine 3.0 ltr. TFSI

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm

Table of tightening torques for installation:


Component/fastener	[Nm]
Sealing cap	25

Removal steps:


- Remove engine cover panel ➔ [page 17](#) .

Procedure:


- Loosen sealing cap of oil filter using socket (36 mm) . This causes a valve to open.
- Wait a few minutes to allow engine oil to drain from filter housing into crankcase.
- Completely remove sealing cap -arrow- of oil filter. Make sure that no engine oil drips onto engine.



- Pull oil filter element and seal -2- out of sealing cap -1-.
- Clean sealing surface -B- of sealing cap -1-.
- Lightly lubricate new seal -2- with engine oil and insert into sealing cap. Note position of service tab -A- on seal. Flat side of seal profile must face outwards.



- Remove O-ring -2- on oil filter housing -1-.
- Lightly lubricate new O-ring -2- with engine oil and insert into groove -arrow-.
- Fit new oil filter element in sealing cap.
- Screw sealing cap into oil filter housing and tighten it to specified torque using socket (36 mm) (see table of tightening torques for installation ➔ [page 84](#)).



Continue installation in reverse sequence.

3.45.4 8-cyl. petrol engine 4.0 ltr. TFSI

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Sealing cap on oil filter	25


Requirements:

- Engine oil drained.

Procedure:

- Loosen sealing cap using socket (32 mm) and remove it.
- Pull oil filter element -5- and O-ring -4- out of sealing cap -3-.
- Clean sealing surfaces of sealing cap.
- Lightly lubricate new O-rings -4- and -6- with engine oil and insert into grooves.
- Fit new oil filter element -5- in sealing cap -3-.
- Fit sealing cap -3- on engine and tighten to appropriate torque using socket (32 mm) (see table of tightening torques for installation ➔ [page 85](#)).

Continue installation in reverse sequence.



3.45.5 4-cyl. diesel engine 2.0 ltr. TDI (version 1)

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm

Table of tightening torques for installation:


Component/fastener	[Nm]
Sealing cap	25

Removal steps:

- Remove engine cover panel ➔ [page 17](#) .

Procedure:

- Loosen sealing cap -1- of oil filter using socket (32 mm) . This causes a valve to open.
- Wait a few minutes to allow engine oil to drain from filter housing into crankcase.
- Completely remove sealing cap. Make sure that no engine oil drips onto engine.



Prepared by Audi AG. Copyright for private or commercial purposes, in part or in whole, is not permitted. Please inform Audi AG. Audi AG is not responsible for any liability with respect to the correctness of instructions in this document. Copyright by Audi AG


- Pull oil filter element -5- and O-ring -2- out of sealing cap -1-.
- Clean sealing surfaces of sealing cap.
- Lightly lubricate new O-rings -2-, -3- and -4- with engine oil and insert O-rings.
- Fit new oil filter element -3- in sealing cap.
- Screw sealing cap into oil filter housing and tighten it to specified torque using socket (32 mm) (see table of tightening torques for installation ➔ [page 86](#)).

Continue installation in reverse sequence.



Note

There is more than one version of the oil filter for the 4-cylinder 2.0 ltr. TDI diesel engine ➔ [page 87](#) .



3.45.6 4-cyl. diesel engine 2.0 ltr. TDI (version 2)

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Sealing cap	25

Protected by copyright. Copying this document or its contents, in whole or in part, is prohibited without permission by Audi AG. Audi AG does not guarantee the content and liability with respect to it in connection with information. Copyright © by Audi AG.

Removal steps:

- Remove engine cover panel ➔ [page 17](#) .

Procedure:

- Loosen sealing cap of oil filter using socket (32 mm) . This causes a valve to open.
- Wait a few minutes to allow engine oil to drain from filter housing into crankcase.
- Completely remove sealing cap. Make sure that no engine oil drips onto engine.


- Pull oil filter element -3- and O-ring -4- out of sealing cap -5-.
- Clean sealing surfaces of sealing cap -5-.
- Lightly lubricate new O-ring -4- with engine oil and insert O-ring.
- Fit new oil filter element -3- in sealing cap.
- Screw sealing cap -5- into oil filter housing -2- and tighten it to specified torque using socket (32 mm) (see table of tightening torques for installation ➔ [page 87](#)).

Continue installation in reverse sequence.



Note

There is more than one version of the oil filter for the 4-cylinder 2.0 ltr. TDI diesel engine ➔ [page 86](#) .



3.45.7 6-cyl. diesel engine 3.0 ltr. TDI

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - VAS 5820- , measuring range 20 to 100 Nm

Table of tightening torques for installation:


Component/fastener	[Nm]
Sealing cap	35

Removal steps:

- Remove engine cover panel ➔ [page 17](#) .


Procedure:

- Loosen sealing cap -arrow- using socket (32 mm) . This causes a valve to open.
- Wait a few minutes to allow engine oil to drain from filter housing into crankcase.
- Completely remove sealing cap. Make sure that no engine oil drips onto engine.



- Pull oil filter element -9- and O-ring -8- out of sealing cap -7-.
- Clean sealing surfaces of sealing cap -7-.
- Lightly lubricate new O-ring -8- with engine oil and insert O-ring.
- Fit new oil filter element -9- in sealing cap.
- Screw sealing cap -7- into oil filter housing -2- and tighten it to specified torque using socket (32 mm) (see table of tightening torques for installation ➔ [page 88](#)).

Continue installation in reverse sequence.



3.46 Engine oil: filling up



Caution

Risk of engine damage if the engine is revved too soon after changing the oil!

- ◆ *The engine must only run at idling speed as long as the oil pressure warning lamp in the instrument cluster is on.*
- ◆ *Increase the engine speed only after the warning lamp has gone out.*

Special tools and workshop equipment required

- ◆ Oil filler funnel - VAS 6842-




Refer to ELSA maintenance table for engine-specific oil capacities and oil grades.

Procedure:

- Fill up engine oil using oil filler funnel - VAS 6842- .

- Then check oil level and adjust if necessary ➔ [page 90](#) .

- For all 4-cylinder petrol engines 1.8 ltr./2.0 ltr. TFSI with oil filler neck on timing chain cover: Clean sealing surface -arrow- on inside of oil filler neck with a lint-free cloth before screwing on filler cap.



3.47 Engine oil: checking oil level and correcting if necessary



Caution

Risk of damage to catalytic converter if engine oil level is too high!

- ◆ Drain engine oil until level meets specification.

This manual is copyrighted. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorized by Audi AG. Audi AG does not guarantee the accuracy, completeness or timeliness of information in this document. Copyright by Audi AG.

Requirements for all engines except V6 diesel engines and V8 petrol engines:

- Engine oil temperature at least 60 °C.
- Wait a few minutes after switching off the engine to allow the oil to flow back into the sump.
- Vehicle must be level (horizontal).

Requirements for V6 diesel engines:

- The engine must be at operating temperature (90 °C oil temperature).
- Wait approx. two minutes after switching off the engine to allow the oil to drain back into the sump.
- Vehicle must be level (horizontal).

Requirements for V8 petrol engines:

- The engine must be at operating temperature (90 °C oil temperature).
- Allow engine to run at idling speed for approx. one minute.
- Switch off engine and wait approx. five minutes (to allow oil to flow back slowly).
- Check engine oil level within one minute.
- Vehicle must be level (horizontal).

Checking oil level with dipstick ⇒ [page 90](#)


Checking oil level on MMI ⇒ [page 91](#)

3.47.1 Checking oil level with dipstick

Procedure:

- Pull out dipstick and wipe it off with a clean cloth.
- Re-insert dipstick into guide tube as far as it will go.

- Pull oil dipstick out again and read off oil level on marked area.
- Evaluate oil level and determine any necessary measures accordingly:



Oil level:	Evaluation/measure:
Marked area -arrow-	Optimum oil level.
Area A	Oil must not be topped up.
Area B	Oil can be topped up.
Area C	Oil must be topped up.

 Note

Some engines are not fitted with an oil dipstick; if this is the case, use the oil level display in the MMI system ➔ [page 91](#) .

3.47.2 Checking oil level on MMI

Procedure:

- If necessary, close bonnet.
- Switch on ignition and activate MMI.
- Press function selector button **CAR**.
- Under »Car systems«, navigate through following menu structure:
 - ◆ Servicing & checks
 - ◆ Oil level
- Read off and evaluate oil level on display.
- If necessary, correct oil level:



Oil level	Evaluation/measure
At "max"	Drain engine oil until level meets optimum level.
Just under "max"	Optimum oil level.
Significantly under "max"	Fill up engine oil to optimum level (close bonnet to refresh oil level display).



Note

- ◆ The oil level display on the MMI is not refreshed when the bonnet is open.
- ◆ A warning lamp in the driver information system indicates that the level is too low.

3.48 Poly V-belts for ancillaries: checking



Caution

Risk of engine damage if camshaft drive slips.

- ◆ Turn crankshaft only in normal direction of engine rotation.

This maintenance item only applies to certain countries: Note specification in Maintenance table.

Removal steps:

- Remove engine cover panel ➔ [page 17](#) .
- Remove poly V-belt ➔ ; Rep. gr. 13 ; Cylinder block (pulley end); Removing and installing poly V-belt .

Procedure:


- Check poly V-belt (removed from vehicle) along entire length, as well as pulleys on engine that are within view. Look for the following types of damage:
 - ◆ Cracks or tears in belt profile and on reverse side (cracks, core fractures, cross-sectional fractures)
 - ◆ Layer separation (top layer, cord strands)
 - ◆ Fraying of cord strands
 - ◆ Foreign objects in belt profile and reverse side
 - ◆ Excessive traces of oil and grease on rollers and pulleys
 - ◆ Flank wear on pulleys (material wear, frayed flanks, surface cracks); see -illustration-
- Applies to vehicles with power steering pump: Check alternator freewheel.
- If damage is found: Renew damaged component.

Install in reverse sequence.



Note

The example given here shows possible damage to a pulley. The appearance of other types of material wear on the load-bearing flanks of the ribbing can be different.



3.49 Spark plugs: renewing

4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/2.0 ltr. TFSI hybrid
⇒ [page 93](#)

6-cyl. petrol engine 2.5 ltr. FSI/2.8 ltr. FSI/3.0 ltr. TFSI
⇒ [page 95](#)

8-cyl. petrol engine 4.0 ltr. TFSI ⇒ [page 98](#)

3.49.1 4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/ 2.0 ltr. TFSI hybrid

Special tools and workshop equipment required

- ◆ Spark plug socket and extension - 3122B-



- ◆ Puller - T40039-



- ◆ Torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:




Component/fastener	[Nm]
Spark plugs	30
Securing bolts for connector rail	5

Removal steps:

- Remove engine cover panel ⇒ [page 17](#) .

Step 1 - removing spark plugs:

- Release and unplug electrical connectors -arrows- from actuators for camshaft adjustment.
- Unscrew bolts for connector rail.
- Release connectors -arrows- and pull all connectors simultaneously off ignition coils.
- Place connector rail slightly to one side. Make sure that wiring is not kinked or damaged.
- Position puller - T40039- on thick rib at top of ignition coils and detach all ignition coils from spark plugs one after the other in direction of -arrow-.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG

- Unscrew spark plugs from cylinder head using spark plug socket - VAS 3122B- .

Step 2 - installing spark plugs:

- Install new spark plugs using spark plug socket and extension - VAS 3122B- and tighten to specified torque (table ⇒ [page 93](#)).
- Fit all ignition coils loosely into spark plug apertures and align with connectors of connector rail.
- Push ignition coils evenly onto spark plugs by hand (do not attempt to knock in coils with any kind of tool).
- Align connector rail and plug all connectors simultaneously onto ignition coils so that they engage.
- Plug electrical connectors into actuators for camshaft adjustment so that they engage.
- Install connector rail, screwing in securing bolts to specified torque (see table of tightening torques for installation ⇒ [page 93](#)).



Continue installation in reverse sequence.

3.49.2 6-cyl. petrol engine 2.5 ltr. FSI/2.8 ltr. FSI/3.0 ltr. TFSI

Special tools and workshop equipment required

- ◆ Spark plug socket and extension - 3122B-



- ◆ Puller - T40039-



- ◆ Torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:


Component/fastener	[Nm]
Spark plugs	30
Securing bolts for connector rail	5

Removal steps:


- Remove engine cover panel ➤ [page 17](#) .

Step 1 - removing spark plugs, cylinder bank (right-side):


- Move fuel line -1- and hose -2- leading to activated charcoal filter clear at air pipe.
- Detach vacuum hose -3- from connection on air pipe.
- Loosen hose clips -arrows- and detach air pipe.
- Remove air cleaner housing ➤ Rep. gr. 24 ; Removing and installing air cleaner housing .



- Release and unplug electrical connectors -2-, -3-, -4-, -5-, -6-, -7-, -8- and -9- from actuators for camshaft adjustment.
- Unplug electrical connector -1- at Hall sender 3 - G300- .
- Unscrew bolts for connector rail.
- Release connectors for ignition coils -arrows- and unplug all connectors from ignition coils at the same time.
- Place connector rail slightly to one side. Make sure that wiring is not kinked or damaged.




- Position puller - T40039- on thick rib at top of ignition coils and detach all ignition coils from spark plugs one after the other in direction of -arrow-.
- Unscrew spark plugs from cylinder head using spark plug socket - VAS 3122B- .




Step 2 - removing spark plugs, cylinder bank (left-side):


- Unplug electrical connector -1- for coolant shortage indicator switch - F66- .
- Unscrew bolt -2- on coolant expansion tank.
- Place coolant expansion tank to one side with coolant hoses -arrows- attached.



- Release and unplug electrical connectors -2-, -3-, -4-, -5-, -6-, -7-, -8- and -9- from actuators for camshaft adjustment.
- Unplug electrical connector -1- at Hall sender 3 - G163- .
- Unscrew bolts for connector rail.
- Release connectors for ignition coils -arrows- and unplug all connectors from ignition coils at the same time.
- Place connector rail slightly to one side. Make sure that wiring is not kinked or damaged.



- Position puller - T40039- on thick rib at top of ignition coils and detach all ignition coils from spark plugs one after the other in direction of -arrow-.
- Unscrew spark plugs from cylinder head using spark plug socket - VAS 3122B- .



Step 3 - installing spark plugs:

- Install new spark plugs using spark plug socket and extension - VAS 3122B- and tighten to specified torque (table ➔ [page 96](#)).
- Fit all ignition coils loosely into spark plug apertures and align with connectors of connector rail.
- Push ignition coils evenly onto spark plugs by hand (do not attempt to knock in coils with any kind of tool).
- Align connector rail and plug all connectors simultaneously onto ignition coils so that they engage.
- Plug electrical connectors into actuators for camshaft adjustment so that they engage.
- Install connector rail, screwing in securing bolts to specified torque (see table of tightening torques for installation ➔ [page 96](#)).

Continue installation in reverse sequence.

3.49.3 8-cyl. petrol engine 4.0 ltr. TFSI

Special tools and workshop equipment required

- ◆ Spark plug socket and extension - 3122B-



- ◆ Puller - T10530-



- ◆ Torque wrench - VAS 6583- , measuring range 3 to 60 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Spark plugs	30
Securing bolts for connector rail	5
Bolts for ignition coils	9

Removal steps:


- Remove engine cover panel ➔ [page 17](#) .

Step 1 - removing spark plugs, cylinder bank (right-side):

- Remove air cleaner housing ➔ Rep. gr. 24 ; Removing and installing air cleaner housing .

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorized by AUDI AG. AUDI AG does not guarantee the content and liability with respect to the correctness of information in this document. Copyright by AUDI AG

-
- 1
2
3
4
5
6
7
- A 28-10070



-


- Carefully pull ignition coil out upwards using puller - T10530- .
- Repeat removal procedure with all other ignition coils.
- Unscrew spark plugs using spark plug socket and extension - VAS 3122B- .

Step 2 - removing spark plugs, cylinder bank (left-side):




Protected by copyright. Copying or reproduction in any form is prohibited without the written permission of Audi AG. Copyright by Audi AG.


- Release retaining clips -1- and -4- and disconnect coolant hoses.
- Move coolant hose -arrow- clear.
- Unplug electrical connector -2- for coolant shortage indicator switch - F66- .
- Unscrew bolt -3- on coolant expansion tank.
- Lift coolant expansion tank out of bracket and place to one side.




- Move clear coolant hoses -3- and air pipe -1- at wiring guide -2-.



- Take electrical connectors -1- out of bracket -2-, unplug connectors and move wiring clear.
- Lift off bracket -2-.



- Unplug electrical connectors -arrows- and move wiring clear.



- Unplug the following electrical connectors and move electrical wiring harness clear:

3 - For inlet/exhaust cam actuators -F464- , -F465- , -F466- and -F467-

4 - For fuel metering valve 2 - N402-


5 - For fuel pressure sender for low pressure - G410-

6 - For Hall sender 4 - G301-


8 - For inlet/exhaust cam actuators -F476- , -F477- , -F478- and -F479-

10 - For Hall sender 2 - G163-

11 - For ignition coils -N323- , -N324- , -N325- , -N326-



- Disconnect vacuum hoses -1- and -7-.
- Remove bolts -2-, -9- and centre hex stud -arrow- and move earth wire clear.
- Push ignition coil connector towards ignition coil, release retainer and detach connector from ignition coil.
- Place connector rail slightly to one side. Make sure that wiring is not kinked or damaged.
- Unscrew bolts -arrows- for ignition coils.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG

- Insert puller - T10530- into hole -1- of ignition coil and turn knurled nut -2- clockwise until puller is secured in place.



- Carefully pull ignition coil out upwards using puller - T10530- .
- Repeat removal procedure with all other ignition coils.
- Unscrew spark plugs using spark plug socket and extension - VAS 3122B- .


Step 3 - installing spark plugs:

- Install new spark plugs using spark plug socket and extension - VAS 3122B- and tighten to specified torque (table ➔ [page 98](#)).
- Fit all ignition coils loosely into spark plug apertures and align with connectors of connector rail.
- Push ignition coils evenly onto spark plugs by hand (do not attempt to knock in coils with any kind of tool).



- Tighten bolts -arrow- for ignition coils to specified torque (see table of tightening torques for installation ➔ [page 98](#)).
- Plug in connector on each ignition coil until it engages.

Continue installation in reverse sequence.



3.50 Cooling system: checking anti-freeze and coolant level, and correcting if necessary



WARNING

Coolant expansion tank under pressure - risk of injuries!

- ◆ Only open coolant expansion tank when engine is cold.

 Note

- ◆ *Coolant additives may only be mixed with distilled water, as the effectiveness of the coolant and the corrosion protection it provides are greatly influenced by the quality of the water with which the coolant is mixed. To ensure an adequate water quality, the coolant additive should be mixed with distilled water.*
- ◆ *For approved coolant additives, refer to Electronic parts catalogue (ETKA).*
- ◆ *G13 and G12++ may be mixed together.*
- ◆ *Coolant additives G13 and G12++ may be mixed with coolant additives G11, G12 and G12+, though this may result in decreased corrosion protection.*
- ◆ *G12 and G11 may NOT be mixed together.*
- ◆ *Do not reuse coolant.*
- ◆ *Only water/coolant additive may be used as lubricant for coolant hoses.*
- ◆ *It is permissible to operate the vehicle if the coolant level is above the MAX marking on the coolant expansion tank (this is by technical design). Do NOT extract coolant.*

Checking coolant level and anti-freeze ➔ [page 103](#)

Filling up coolant ➔ [page 105](#)

3.50.1 Checking coolant level and anti-freeze

Special tools and workshop equipment required

- ◆ Refractometer - T10007 A-



Table of test values and procedure guidelines:

Type of service:	Coolant level specification:
Delivery Inspection	Coolant at level of MAX marking.
Inspection	Coolant level between MIN and MAX markings.

Checking the coolant system for leaks is a repair measure and should be charged separately.


Requirements:

- Anti-freeze protection must be guaranteed to -25 °C (in countries with an arctic climate to -36 °C); note specification in Maintenance table.

- The proportion of coolant additive must not exceed 55 % (gives anti-freeze protection down to -48 °C); beyond this concentration the frost protection and the cooling efficiency are reduced again.
- The vehicle must be parked on a level surface.

Step 1 - checking coolant level:

- Check coolant level (according to marking -illustration-) in coolant expansion tank with engine cold.
- If coolant level is too low: Add required amount (using correct mixture ratio) ⇒ [page 105](#) .
- If fluid losses are greater than can be reasonably expected: First use a leak test to determine the cause ⇒ Engine; Rep. gr. 19 ; Cooling system/coolant; Checking cooling system for leaks .



Step 2 - checking anti-freeze:

- Use a pipette to place a drop of coolant on glass of refractometer - T10007 A- . Light-dark border will now be clearly visible through refractometer.
- Check level of anti-freeze protection using corresponding scale on refractometer; to do so, read off value on light-dark border.
- If anti-freeze protection level does not meet specification in Maintenance table: Perform following measures:

Copyright © 2015 Audi AG. All rights reserved. This document is the property of Audi AG. It is not permitted to reproduce, distribute, or otherwise use this document without the written consent of Audi AG. The content of this document is subject to change without notice.


Anti-freeze protection level: Evaluation/measure:

- | | |
|-----------------|---|
| > Specification | Depending on deviation from specification, remove a small amount of coolant and replace it with distilled water. Repeat procedure until coolant mixture meets correct specification. |
| < Specification | Depending on deviation from specification, remove a small amount of coolant and replace it with coolant additive. Repeat procedure until coolant mixture meets correct specification. |
- Check coolant additive concentration once more following road test.



Note

- ◆ The refractometer - T10007 A- must be used to determine the current anti-freeze concentration.
- ◆ Scale -1- on the refractometer applies to coolant additives G11, G12, G12+ and G12++.
- ◆ Scale -2- refers only to coolant additive G13.
- ◆ If more than one type of coolant additive has been used: Always use the scale for G13 to determine the anti-freeze protection.
- ◆ The temperature indicated on the refractometer - T10007 A- corresponds to the temperature at which the first ice crystals can form in the coolant.
- ◆ It is essential that anti-freeze be used in the cooling system all year round. In the correct concentration, coolant additives prevent scaling and frost and corrosion damage, and also raise the boiling point of the coolant.
- ◆ Because of its high boiling point, the coolant improves engine reliability under heavy loads in countries with tropical climates.



3.50.2 Filling up coolant

Table of test values and procedure guidelines:

Frost protection to:	Coolant additive:	Water:
-25 °C	approx. 40 %	approx. 60 %
-36 °C	approx. 50 %	approx. 50 %

Procedure:

- Add required amount (using mixture ratio according to anti-freeze protection specification in Maintenance table). Use the table as a reference for the coolant mixture ratio.



Note

Small quantities of coolant can simply be topped up. Use the cooling system charge unit - VAS 6096- to add larger quantities of coolant.

3.51 Air cleaner: renewing filter element and cleaning housing



Note

- ◆ Use only silicone-free lubricants when installing intake hoses.
- ◆ Secure all hose connections with hose clips (same as original equipment); see *Electronic parts catalogue (ETKA)*.

Air cleaner housing: cleaning ➔ [page 113](#)

4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/2.0 ltr. TFSI hybrid
➔ [page 106](#)

6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI ➔ [page 107](#)

6-cyl. petrol engine 3.0 ltr. TFSI ➔ [page 108](#)

8-cyl. petrol engine 4.0 ltr. TFSI ➔ [page 110](#)

4-cyl. diesel engine 2.0 ltr. TDI ➔ [page 110](#)

6-cyl. diesel engine 3.0 ltr. TDI ➔ [page 112](#)

3.51.1 4-cyl. petrol engine 1.8 ltr./2.0 ltr. TFSI/ 2.0 ltr. TFSI hybrid


Removal steps:

- Remove engine cover panel ➔ [page 17](#) .

Step 1 - removing air filter element:


- Release hose clip -3- and detach air pipe.
- Unplug electrical connector -2- for air mass meter - G70- .

Protected by copyright. Copying for private or commercial purposes,
permitted unless authorised by AUDI AG. AUDI AG does not guarantee
with respect to the correctness of information in this document. Co




- Release retainer -1-.
- Turn filter element in anti-clockwise direction -arrow A- and remove it.


Step 2 - installing air filter element:




- Check for dirt in housing and water drains -arrow- and clean if necessary ➔ [page 113](#) .



- Insert new filter element -1- centrally in housing cover -2-. Ensure that filter element is installed in correct direction and that all centring lugs engage in housing cover.



- Fit housing cover (with filter element attached) centrally into mounting in air cleaner housing and turn it in clockwise direction -arrow B- until it engages -1-.
 - Attach air pipe to air cleaner (top section) and fit hose clip.
 - Plug electrical connector for air mass meter - G70- back in.
- Continue installation in reverse sequence.




3.51.2 6-cyl. petrol engine 2.5 ltr./2.8 ltr. FSI

Removal steps:

- Remove engine cover panel ➔ [page 17](#) .


Step 1 - removing air filter element:

- Disengage fuel line -1- and hose -2- from retainer on air pipe.
- Disconnect vacuum hose -3- from air pipe.
- Loosen hose clips -arrows- and detach air pipe.




- Release retainer -1-.
- Turn filter element in anti-clockwise direction -arrow A- and remove it.

Step 2 - installing air filter element:




Protected by copyright. Copying for
permitted unless authorised by Audi AG
with respect to the correctness


- Check for dirt in housing and water drains -arrow- and clean if necessary ➔ [page 113](#) .



- Insert new filter element -1- centrally in housing cover -2-. Ensure that filter element is installed in correct direction and that all centring lugs engage in housing cover.



- Fit housing cover (with filter element attached) centrally into mounting in air cleaner housing and turn it in clockwise direction -arrow B- until it engages -1-.
 - Attach air pipe to air cleaner (top section) and fit hose clip.
- Continue installation in reverse sequence.




3.51.3 6-cyl. petrol engine 3.0 ltr. TFSI

Removal steps:

- Remove engine cover panel ➔ [page 17](#) .

Step 1 - removing air filter element:

- Disengage fuel line -1- and hose -2- from retainer on air pipe.
- Disconnect vacuum hose -3- from air pipe.
- Loosen hose clips -arrows- and detach air pipe.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Release retainer -1-.
- Turn filter element in anti-clockwise direction -arrow A- and remove it.

Step 2 - installing air filter element:

- Check for dirt in housing and water drains -arrow- and clean if necessary ➔ [page 113](#) .




- Insert new filter element -1- centrally in housing cover -2-. Ensure that filter element is installed in correct direction and that all centring lugs engage in housing cover.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee the accuracy of the information with respect to the correctness of information in this document. Copyright by Audi AG.



- Fit housing cover (with filter element attached) centrally into mounting in air cleaner housing and turn it in clockwise direction -arrow B- until it engages -1-.
- Attach air pipe to air cleaner (top section) and fit hose clip.

Continue installation in reverse sequence.



3.51.4 8-cyl. petrol engine 4.0 ltr. TFSI

Step 1 - removing air filter element:




- Release hose clips -2- and detach air pipe.
- Release retainer -3-.
- Turn housing cover in anti-clockwise direction -arrow B- and remove filter element.

Step 2 - installing air filter element:

- Check for dirt in housing and water drains -arrow- and clean if necessary ➔ [page 113](#) .
- Fit new filter element centrally in housing cover, ensuring that it is installed in correct direction.

- Fit housing cover (with filter element attached) centrally into mounting in air cleaner housing and turn it in clockwise direction -arrow A- until it engages -3-.
- Attach air pipe to air cleaner (top section) and fit hose clip.

Continue installation in reverse sequence.



3.51.5 4-cyl. diesel engine 2.0 ltr. TDI


Removal steps:

- Remove engine cover panel ➔ [page 17](#) .

This document is a technical manual for the Audi A6 2011 and Audi A7 Sportback 2011. It is published by Audi AG. Audi AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by Audi AG

Step 1 - removing air filter element:


- Unplug electrical connector -2- for air mass meter - G70- .
- Release hose clip -3- and detach air pipe.




- Release retainer -1- on housing cover.
- Turn housing cover with filter element in anti-clockwise direction -arrow A- and remove it.

Step 2 - installing air filter element:


Protected by copyright. Copying for private use is permitted unless authorised by AUDI AG. All rights reserved. with respect to the correctness of the content.



- Check for dirt in housing and water drains -arrow- and clean if necessary ➔ [page 113](#) .



- Insert new filter element -1- centrally in housing cover -2-. Ensure that filter element is installed in correct direction and that all centring lugs engage in housing cover.
- Fit housing cover (with filter element attached) into mounting of air cleaner housing so that it is centred. When fitting, hold onto filter element as you insert it through opening for housing cover; ensure that it does not slip off centring lugs and become tilted when it is installed.




- Turn housing cover in clockwise direction -arrow B- until you feel it engage -1-.
 - Attach air pipe to air cleaner (top section) and fit hose clip.
 - Plug electrical connector for air mass meter - G70- back in.
- Continue installation in reverse sequence.



Note

If the housing cover does not engage easily, this may indicate that the air filter element is not aligned properly or is tilted.




3.51.6 6-cyl. diesel engine 3.0 ltr. TDI

Removal steps:

- Remove engine cover panel ➔ [page 17](#) .


Step 1 - removing air filter element:

- Release hose clips -arrows- and detach air pipe -1-.




- Release retainer -1-.
- Turn filter element in anti-clockwise direction -arrow A- and remove it.


Step 2 - installing air filter element:




- Check for dirt in housing and water drains -arrow- and clean if necessary ➔ [page 113](#) .



- Insert new filter element -1- centrally in housing cover -2-. Ensure that filter element is installed in correct direction and that all centring lugs engage in housing cover.



- Fit housing cover (with filter element attached) centrally into mounting in air cleaner housing and turn it in clockwise direction -arrow B- until it engages -1-.
 - Attach air pipe to air cleaner (top section) and fit hose clip.
- Continue installation in reverse sequence.



3.51.7 Cleaning air cleaner housing

Procedure:

- Remove any loose dirt or leaves out of air cleaner housing (top and bottom sections).
- Check whether water drain hose in air cleaner (bottom section) is dirty or blocked and clean if necessary.



Note

- ◆ When cleaning air cleaner housing with compressed air: Cover air mass meter with a clean cloth.
- ◆ On vehicles for cold countries, the snow screen in the intake section must also be cleaned; see specification in ELSA Maintenance table.

3.52 Plenum chamber and water drains: checking for dirt



DANGER!

Risk of fatal injury if high-voltage components are damaged.

- ◆ Observe warnings for high-voltage system:

- ◆ Handling high-voltage wires ➔ [page 12](#).

- ◆ For work in the vicinity of high-voltage components ➔ [page 11](#).

Protected by copyright. Copying for private or commercial purposes in print or in whole is not permitted. Audi AG does not guarantee or accept any liability with regard to the correctness of information in this document. Copyright by AUDI AG

Checking plenum chamber and water drains for dirt

⇒ [page 114](#)

Cleaning plenum chamber and water drain valves ⇒ [page 115](#)

3.52.1 Checking plenum chamber and water drains for dirt

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1783- , measuring range 2 to 10 Nm
- ◆ Or: torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm
- ◆ Or: torque wrench - VAS 6854- , measuring range 5 to 13 Nm
- ◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm
- ◆ Or: torque wrench - V.A.G 1331- , measuring range 6 to 50 Nm

Table of tightening torques for installation:

Component/fastener	[Nm]
Bolts for washer fluid reservoir	8

Cleaning the plenum chamber, as well as the removal procedures required, are a repair measure and should be charged separately.



Removal steps:

- Remove plenum chamber cover ⇒ General body repairs, exterior; Rep. gr. 50 ; Bulkhead; Removing and installing plenum chamber cover .
- Remove bolts -arrows- for washer fluid reservoir -1-.
- Carefully lift filler neck, but do not remove completely.

Step 1 - checking plenum chamber and water drains (driver's side):

- Check for dirt in water drain grommet -1- and bottom of plenum chamber using a hand-held light.
- If no dirt was found: Carefully pour a small amount of water into plenum chamber and check that water drains quickly and fully.
- If necessary, clean plenum chamber and water drains
⇒ [page 115](#) .

Step 2 - checking plenum chamber and water drains (passenger's side):




- Check for dirt in water drain grommet -1- and water drains -arrows- using a hand-held light.
- If necessary, clean plenum chamber and water drains
⇒ [page 115](#) .

Install in reverse sequence. Note tightening torques (see table of tightening torques for installation ⇒ [page 114](#)).



Note

If the water you have poured in does not drain out or drains out very slowly, this is a sign that the water drains -arrows- are fully or partly blocked.



3.52.2 Cleaning plenum chamber and water drains

Special tools and workshop equipment required

- ◆ Suction feed spray-gun - VAG 1538-
- ◆ Nylon probe - VAG 1538/2-
- ◆ Flexible picking tool

Cleaning the plenum chamber, as well as the removal procedures required, are a repair measure and should be charged separately.

Procedure:

- Remove coarse dirt from plenum chamber and water drain grommets with a flexible picking tool.
- Remove fine dirt using suction-feed spray gun - V.A.G 1538- and nylon probe - V.A.G 1538/2- or a thin water hose.

3.53 Dust and pollen filter: renewing

Preliminary filter ⇒ [page 115](#)

Main filter ⇒ [page 116](#)

3.53.1 Preliminary filter

Equipment version for certain countries: Note specification in Maintenance table.

The preliminary filter is fitted in the vehicle plenum chamber.

Removal steps:

- Remove plenum chamber cover ⇒ General body repairs, exterior; Rep. gr. 50 ; Bulkhead; Removing and installing plenum chamber cover .


Step 1 - removing filter element:

- Release retainer -1-.
- Take out filter element -2- under retainers -3- in direction of -arrow-.

Step 2 - installing filter element:

- Clean surrounding area (e.g. with a vacuum cleaner) after removing filter element.
- Fit new filter element -2- so that arrows indicating direction of flow point downwards.

Continue installation in reverse sequence.



3.53.2 Main filter

The dust and pollen filter is fitted under the glove box.


Removal steps:

- On vehicles with special equipment used by driving schools: Remove pedal cluster if necessary; see installation instructions for equipment for driving schools.

Step 1 - removing filter element:

- Cover footwell beneath dust and pollen filter with paper.
- Release quick-release fastener -2- with screwdriver -1-.
- Disengage cover -3- at retainer -4- and detach.

Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG - AUDI AG does not guarantee the correctness of information in this document.




- Release retaining tab -B-, swivel cover -A- for aperture down and detach.
- Pull filter element -D- out of aperture -E- in direction of -arrow-.

Step 2 - installing filter element:

- Clean aperture -E- with a vacuum cleaner before fitting new filter element.
- Fit new filter element -D- correctly: angled side faces fresh air blower.
- Position aperture cover -A- in tab -C- and engage on opposite side -B-.

Continue installation in reverse sequence.



3.54 Fuel filter: draining



WARNING

Fuel is hot and under pressure - risk of injuries!

- ◆ *Wear protective gloves.*
- ◆ *Wear safety goggles.*
- ◆ *Loosen draining valve carefully.*

Special tools and workshop equipment required

- ◆ Torque wrench - V.A.G 1783- , measuring range 2 to 10 Nm
- ◆ Or: torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm
- ◆ Or: torque wrench - VAS 6854- , measuring range 5 to 13 Nm
- ◆ Diesel-resistant hose with appropriate diameter: must not slip off draining valve under system pressure
- ◆ Container for collecting fluid


Table of tightening torques for installation:

Fastener	Tightening torque [Nm]
Water drain plug -5-	10

The fuel filter is located on the underbody at the rear of the vehicle.

Procedure:

- Attach hose to water drain plug -5- on cover of filter housing. Place opposite end of hose in appropriate container.
- Start the engine. System pressure is necessary for draining fuel filter.
- Open water drain plug slowly until water begins to drain.
- When diesel fuel begins to drain: Screw water drain plug back in.
- Turn off engine and disconnect hose from water drain plug.
- Tighten water drain plug -5- to specified torque (see table of tightening torques for installation ➔ [page 117](#)).



3.55 Fuel filter: renewing



WARNING

Fuel is hot and under pressure - risk of injuries!

- ◆ *Wear protective gloves.*
- ◆ *Wear safety goggles.*
- ◆ *Allow connections of fuel lines to cool down.*
- ◆ *Place cloths around connections and loosen them carefully.*


Fuel filter without water separator ➔ [page 118](#)

Fuel filter with water separator ➔ [page 119](#)

3.55.1 Fuel filter without water separator

Special tools and workshop equipment required

- ◆ Hose clip pliers - VAS 6362-



- ◆ Torque wrench - V.A.G 1783- , measuring range 2 to 10 Nm
- ◆ Container for collecting fluid

Table of tightening torques for installation:

Fastener	Tightening torque [Nm]
Nuts on bracket	2


The fuel filter is located on the underbody.

Removal steps:

- Remove underbody trim (right-side) ⇒ Rep. gr. 66 ; Underbody trim; Removing and installing underbody trim .

Step 1 - removing:

- Observe the safety precautions when working on the fuel system ⇒ Fuel supply system, diesel engines; Rep. gr. 00 ; Safety precautions; Safety precautions when working on the fuel system .
- Unscrew nuts -2-.
- Swivel bracket downwards, disengage it from mounting points -arrows- and detach it.
- Place drip tray under fuel filter.




- Use hose clip pliers to disconnect fuel supply hoses -1- and -3- and detach fuel filter -2-.

Step 2 - installing:

Install in reverse sequence. Note tightening torques (see table of tightening torques for installation ⇒ [page 119](#)).

Flow direction is indicated by arrows on filter housing.


- Then bleed fuel system ⇒ Engine; Rep. gr. 23 ; Injection system; Filling/bleeding fuel system .



3.55.2 Fuel filter with water separator

Special tools and workshop equipment required

◆ Diesel extractor - VAS 5226-



◆ Hose clamps, up to Ø 25 mm - 3094-



◆ Torque wrench - V.A.G 1783- , measuring range 2 to 10 Nm

◆ Or: torque wrench - V.A.G 1410- , measuring range 4 to 20 Nm

◆ Or: torque wrench - VAS 6854- , measuring range 5 to 13 Nm

◆ Or: torque wrench - VAS 6583- , measuring range 3 to 60 Nm


Table of tightening torques for installation:

Fastener	Tightening torque [Nm]
Water drain plug -5-	10
Bolts for filter housing -8-	9

Protected by copyright. Copying for private or commercial purposes in part or in whole is not permitted without the express permission of Audi AG. Audi AG's does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by Audi AG.

Step 1 - removing:

- Clamp off supply hose for underbody hose -14- with hose clamps, up to Ø 25 mm - 3094- .
- Fit hose of diesel extractor - VAS 5226- together with suitable adapter onto water drain plug -5-.
- Open water drain plug -5-.
- Operate diesel extractor - VAS 5226- until no more diesel emerges.
- Tighten water drain plug -5- to specified torque (see table of tightening torques for installation ➔ [page 120](#)).
- Unscrew bolts -8- and detach filter housing.
- Remove filter element -4- and seal -3- from filter housing -9-.
- Use diesel extractor - VAS 5226- to draw off remaining diesel fuel.
- Clean filter housing -9-.



Step 2 - installing:

- Insert new filter element in filter housing so that it is centred.
- Fit new seal.
- Insert and align filter housing. Make sure that filter housing is screwed on in correct position.
- Fit bolts for filter housing -8- and tighten to specified torque (see table of tightening torques for installation ➔ [page 120](#)).
- Remove hose clamps, up to Ø 25 mm - 3094- from supply hose for underbody hose.
- Finally, bleed fuel system ➔ Rep. gr. 23 ; Injection system; Filling/bleeding fuel system .

3.56 Fuel tank: adding fuel additive

Special tools and workshop equipment required

- ◆ Multi-purpose additive for petrol fuels - G 001 770 A2-
- ◆ Or: Multi-purpose additive for petrol fuel - G 001 780 M3-

Table of test values and procedure guidelines:

China	Russia	India
VW 507 53 B: Applies to all petrol engines	VW 507 53 B: Applies to all petrol engines VW 507 53 A: Applies to all petrol engines except g-tron and E85 flexible fuel	VW 507 53 B: Applies to all petrol engines VW 507 53 A: Applies to all petrol engines except g-tron and E85 flexible fuel
Multi-purpose additive for petrol fuels - G 001 780 M3-	Multi-purpose additive for petrol fuels - G 001 780 M3- Multi-purpose additive for petrol fuels - G 001 770 A2-	Multi-purpose additive for petrol fuels - G 001 780 M3- Multi-purpose additive for petrol fuels - G 001 770 A2-

This maintenance item only applies to certain countries: Note specification in Maintenance table.

Procedure:

- Follow measuring guidelines on fuel additive container and add fuel additive to fuel tank according to current fuel tank level.



Note

- ◆ *Use only fuel additives that correspond to the standard VW 507 53 A or VW 507 53 B.*
- ◆ *After adding fuel additive, it is very important to tell the customer to fill up the fuel tank.*

3.57 Reducing agent (AdBlue®): filling up tank completely



WARNING

Risk of injury due to contact with reducing agent!

- ◆ *Do not kink lines of filling device.*
- ◆ *If you come into contact with this liquid: Rinse it off immediately with plenty of water and contact a medical professional.*




Caution

Risk of damage to trim and body components due to contact with reducing agent!

- ◆ *Do not kink lines of filling device.*
- ◆ *Clean the affected areas with clean water and a cotton cloth.*
- ◆ *Remove any crystallised reducing agent using warm water and a sponge.*

Special tools and workshop equipment required


- ◆ Filling device for AdBlue - VAS 6542-



◆ Engine and gearbox jack - VAS 6931-




◆ Mounting plate - V.A.G 1383A/1-



Components of filling device -VAS 6542-

- 1 - Breather connection for reducing agent container
- 2 - Union nut for reducing agent container
- 3 - Cut-off valve for breather line
- 4 - Quick-release coupling on breather line
- 5 - Filler line
- 6 - Cut-off valve for filler line
- 7 - Union nut for tank filler neck
- 8 - Breather line




Procedure:

- Open tank flap and unscrew filler cap for reducing agent tank.
- Clean filler neck of tank for reducing agent with a lint-free cotton cloth soaked with water.
- Close cut-off valves of breather and filler lines of filling device for AdBlue - VAS 6542- .
- Apply filling device for AdBlue - VAS 6542- to reducing agent container (see Electronic parts catalogue, ETKA) and screw it on as far as stop.


- Position reducing agent container on engine and gearbox jack - VAS 6931- with mounting plate - V.A.G 1383A/1- . Difference in height of reducing agent container and filler neck of tank for reducing agent must be between 60 - 80 cm -dimension A-.



Protected by Copyright. Copying for private or commercial purposes is permitted without charge. Audi ZVE A 1. Audi reserves all rights of responsibility with respect to the correctness of information. Audi ZVE A 1. Audi ZVE A 1.



- Position filling device for AdBlue - VAS 6542- on filler neck on vehicle and screw it on as far as stop.
- Open cut-off valve for breather line.
- Open cut-off valve for filler line and fill reducing agent tank of vehicle completely. Tank is completely full when container contracts and bleeder line fills with liquid.
- Close cut-off valve for filler line.
- Close cut-off valve for breather line.
- Disconnect quick-release coupling on breather line and let any excess liquid flow into a suitable container.
- Unscrew filling device for AdBlue - VAS 6542- from tank filler neck.
- Clean filler neck and filler cap with a lint-free cotton cloth soaked with water.
- Screw filler cap onto reducing agent tank.
- Take container off mounting plate and put it on the floor.
- Open cut-off valve on filler line and let remaining liquid drain back into container.
- Unscrew filling device for AdBlue - VAS 6542- from container.



Note

- ◆ *The reducing agent is statutory for vehicles with SCR system.*
- ◆ *The reducing agent is used for the after-treatment of exhaust gases of diesel-engined vehicles, i.e. to reduce the level of nitrogen oxides.*
- ◆ *The reducing agent is not a diesel additive and must not be filled into the diesel fuel tank.*
- ◆ *Do not add any additives to the reducing agent, and do not dilute it with water.*
- ◆ *Only use the reducing agent as supplied in its original container.*
- ◆ *In addition, please observe the reducing agent manufacturer's notices on usage and storage.*

3.58 Body: checking vehicle paintwork for damage and corrosion from below and with bonnet, rear lid and doors open

Procedure:

- Open all vehicle doors, bonnet and rear lid.
- Check vehicle paintwork on inside and outside of body for damage and corrosion.
- Rectify defects of any kind (repair measure).

3.59 Road test

Procedure:

- The following points must be checked during the road test:
- ◆ Engine: performance, misfiring, idling speed, acceleration, starting behaviour (engine cold and warm), engine noise

- ◆ Clutch: pulling away, pedal pressure, odours, noise due to load change
- ◆ Manual gearbox: ease of operation, gear lever position, gearbox noise
- ◆ Automatic gearbox: selector lever position, shift lock / ignition key lock, gearbox noise, kickdown, shift behaviour, instrument cluster display
- ◆ Brake pedal and handbrake: operation, travel and effectiveness, pulling to one side, response (delayed braking), juddering, squeal
- ◆ ABS function: pulsing must be felt at the brake pedal when performing ABS-controlled braking.
- ◆ Steering: operation, steering free play, steering wheel centralised when wheels are in straight-ahead position, moving off line when travelling straight
- ◆ Imbalance: wheels, drive shafts
- ◆ Wheel bearings: noises
- ◆ Roof insert: unusual noise during operation
- ◆ Horn: checking
- ◆ Hybrid vehicles: check electrical operation by pressing EV button, charging function in overrun phases



Note

To what extent all of these can be checked depends on vehicle equipment and local conditions (urban/country).

3.60 Stock vehicles: observing measures specified in Maintenance table for stock vehicles (see "Before handing vehicle over to customer")

This maintenance item only applies to stock vehicles.

Procedure:

- Before handing vehicle over to customer: Check whether the following three measures for stock vehicles (as specified in the Maintenance table) are due, and carry them out as necessary:
 - ◆ For vehicles older than 12 months (from date of manufacture): Renew brake fluid ⇒ [page 43](#) .
 - ◆ For vehicles with a defective battery: Renew battery ⇒ Electrical system; Rep. gr. 27 ; Battery; Removing and installing battery; Removing and installing battery, vehicles without high-voltage system .
 - ◆ Check brake discs for surface rust; if necessary, operate brakes to remove rust according to manufacturer's instructions.
- Record measures performed in maintenance table for stock vehicles.

3.61 Rear final drive: changing gear oil

Procedure:

- Change gear oil according to Workshop Manual ⇒ Rep. gr. 39 ; Gear oil; Draining and filling gear oil .

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability for the correctness of information in this document. Copyright by AUDI AG.

3.62 Rear final drive: changing ATF

Procedure:

- Change ATF according to Workshop Manual ⇒ Rep. gr. 39 ; ATF; Draining and filling ATF .

3.63 Display instruments: setting language, time and date

Procedure:

- Change settings of display instruments: Refer to Operating Manual for radio/sound system/MMI system.

3.64 Automatic gearbox (multitronic): changing ATF

Procedure:

- Change ATF according to Workshop Manual ⇒ Rep. gr. 37 ; ATF; Draining and filling ATF .

3.65 Automatic gearbox (tiptronic): changing ATF fluid

Procedure:

- Change ATF fluid according to Workshop Manual ⇒ ; Rep. gr. 37 ; ATF; Draining and filling ATF .

3.66 Dual clutch gearbox (S tronic): changing ATF

- Change ATF according to Workshop Manual ⇒ Rep. gr. 34 ; ATF; Draining and filling ATF .

3.67 Dual clutch gearbox (S tronic): changing ATF and renewing exchangeable ATF filter

Procedure:

- Change ATF according to Workshop Manual ⇒ Rep. gr. 34 ; ATF; Draining and filling ATF .
- Change exchangeable ATF filter according to Workshop Manual ⇒ ; Rep. gr. 34 ; ATF circuit; Removing and installing ATF filter .

3.68 Interior mirror: calibrating compass



WARNING

Risk of injury as engine of high-voltage vehicle can start unexpectedly!

- ◆ *Observe warnings for high-voltage system:*
- ◆ *For work that must be performed with the ignition switched on ⇒ [page 13](#) .*

Procedure:

- Calibrate compass according to Workshop Manual ⇒ General body repairs, interior; Rep. gr. 68 ; Interior mirror; Calibrating digital compass .

3.69 Poly V-belt for supercharger with charge air coolers: renewing

Procedure:

- Renew poly V-belt for supercharger with charge air coolers according to specifications in Workshop Manual ⇒ ; Rep. gr. 13 ; Cylinder block (pulley end); Removing and installing poly V-belt .

3.70 Poly V-belts for ancillaries: renewing

Procedure:

- Renew poly V-belt for ancillaries according to specifications in Workshop Manual ⇒ ; Rep. gr. 13 ; Cylinder block (pulley end); Removing and installing poly V-belt .

3.71 Poly V-belts for ancillaries and pulleys for coolant pump and power steering pump: renewing

Procedure:

- Renew poly V-belt for ancillaries according to specifications in Workshop Manual ⇒ ; Rep. gr. 13 ; Cylinder block (pulley end); Removing and installing poly V-belt .
- Renew pulleys according to Workshop Manual ⇒ ; Rep. gr. 13 ; Cylinder block (pulley end); Exploded view - cylinder block (pulley end) .

3.72 Instrument cluster: resetting driver information system

Procedure:

- Reset single journey memory and total journey memory of driver information system; refer to vehicle Owner's Manual.

3.73 Toothed belt for camshaft drive: renewing

Procedure:

- Renew toothed belt for camshaft drive according to specifications in Workshop Manual ⇒ ; Rep. gr. 15 ; Toothed belt drive; Removing and installing toothed belt .

3.74 Toothed belt for camshaft drive, and drive sprockets for camshaft, crankshaft and high-pressure pump: renewing

Procedure:

- Renew toothed belt for camshaft drive according to specifications in Workshop Manual ⇒ ; Rep. gr. 15 ; Toothed belt drive; Removing and installing toothed belt .
- Renew drive sprockets for camshaft, crankshaft and high-pressure pump according to Workshop Manual ⇒ ; Rep. gr. 15 ; Toothed belt drive; Exploded view - toothed belt .

3.75 **Toothed belt for camshaft drive and tensioning roller: renewing**

Procedure:

- Renew toothed belt for camshaft drive according to specifications in Workshop Manual ⇒ ; Rep. gr. 15 ; Toothed belt drive; Removing and installing toothed belt .
- Renew tensioning roller according to Workshop Manual ⇒ ; Rep. gr. 15 ; Toothed belt drive; Exploded view - toothed belt .

3.76 **Poly V-belts for ancillaries and pulley for power steering pump: renewing**

Procedure:

- Renew poly V-belt for ancillaries according to specifications in Workshop Manual ⇒ ; Rep. gr. 13 ; Cylinder block (pulley end); Removing and installing poly V-belt .
- Renew pulley for power steering pump according to Workshop Manual ⇒ Running gear, axles, steering; Rep. gr. 48 ; Hydraulic power steering; Exploded view - power steering pump .



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.